

User Manual CIFX Cards Real Time Ethernet

Installation, Operation and Hardware Description

Language: English

www.hilscher.com

Table of Contents

1	INTR	ODUCTIO	N	6
	1.1	About the	e User Manual	6
		1.1.1	List of Revisions	7
		1.1.2	Reference on Hardware and Software	8
		1.1.3	Conventions in this Manual	
	1.2	Contents	s of the Product CD	9
		1.2.1	Directory Structure of the CD	9
		1.2.2	Documentations cifX Cards	10
	1.3	Legal No	otes	11
		1.3.1	Guarantee	
		1.3.2	Registered Trademarks	
	1.4	Licenses	S	11
2	SAFE	TY		12
	2.1	Intended	I Use	12
	2.2	Personn	el Qualification	13
	2.3	Labeling	of Safety Instructions	13
	2.4	Safety In	nstructions	14
		2.4.1	Electrical Current	14
		2.4.2	Electrostatic Discharge	14
	2.5	Safety In	nstructions USA	15
		2.5.1	Electrical Current	15
		2.5.2	Electrostatic Discharge	15
3	DESC	CRIPTION	AND REQUIREMENTS	16
	3.1	Descripti	ion	16
	3.2	System Requirements17		
	3.3	Requirer	nents for Operation	
		3.3.1	cifX Slave Device	
		3.3.2	cifX Master Device	
4	GET	TING STAF	RTET	19
	4.1	Steps ho	w to install and configure cifX Slave Devices	19
	4.2	Steps ho	ow to install and configure cifX Master Devices	
5	INST	ALLING CI	FX CARD	21
	5.1	Safetv A	dvices	
		5.1.1	Safety Advices USA	21
	5.2	CIFX 50-	-RE and CIFX 50E-RE	
		5.2.1	Fix Front Plate Sticker	

Cor	nmunica	ation Interface Hilscher cifX-RE Ta	Table of Contents • 3	
	5.3	CIFX 80-RE	24	
		5.3.1 Fix Front Plate Sticker	25	
	5.4	CIFX 90-RE	26	
	5.5	CIFX 104C-RE and CIFX 104C-RE-R	27	
	5.6	CIFX 104C-RE\F and CIFX 104C-RE-R\F	27	
6	INST/	ALLING SOFTWARE		
	6.1	Installing cifX Device Driver	28	
	6.2	Installing the netX Configuration and Diagnostic Utility	33	
	6.3	Installing SYCON.net		
7	NETX	CONFIGURATION AND DIAGNOSTIC UTILITY		
	7.1	Configuration Steps cifX Card	34	
	7.2	Starting netX Configuration and Diagnostic Utility	35	
	7.3	Introduction to the Dialog Structure	35	
		7.3.1 General Buttons		
		7.3.2 Help		
	7 4	Verking with petX Configuration and Diagnostic Litility		
	7.4	7.4.1 Selecting Language / Firmware, downloading Firmware		
		7.4.2 Configuration	41	
		7.4.3 Diagnostics	43	
8	TROL	UBLESHOOTING	47	
9	DEVI	CE DRAWINGS AND CONNECTIONS		
	9.1	Device Drawing CIFX 50-RE	48	
	9.2	Device Drawing CIFX 50E-RE		
	9.3	Device Drawing CIFX 80-RE		
	9.4	Device Drawing CIFX 90-RE		
	9.5	Device Drawing CIFX 104C-RE	50	
	9.6	Device Drawing CIFX 104C-RE-R	50	
	9.7	Device Drawing CIFX 104C-RE\F	51	
	9.8	Device Drawing CIFX 104C-RE-R\F51		
	9.9	Device Drawing Connection Interface AIFX-RE52		
	9.10	Device Drawing Diagnosis Interface AIFX-DIAG	52	
	9.11	Ethernet Interface	53	
		9.11.1 Ethernet pinning at the RJ45 Socket	53	
		9.11.2 Ethernet Connection Data	53	
	0.45	9.11.3 Use of Hubs and Switches		
	9.12	MINI-B USB Connector (5 Pin)	55	
	9.13	Rotary Switch for Slot Number	55	

Con	nmunica	tion Interfa	ce Hilscher cifX-RE	Table of Contents • 4
	9.14	Cable Cor	nector	
		9.14.1	Pinning for Cable Connector Ethernet	
		9.14.2	Pinning for Cable Connector DIAG	
		9.14.3	Pinning for SYNC Connector, X51	
10	LED			58
	10.1	LED Real	Time Ethernet Svstems	
	-	10.1.1	LED Names for each Real Time Ethernet System	
		10.1.2	LED EtherCAT Master	
		10.1.3	LED EtherCAT Slave	
		10.1.4	LED EtherNet/IP Scanner (Master)	61
		10.1.5	LED EtherNet/IP Adapter (Slave)	
		10.1.6	LED Open Modbus/TCP	
		10.1.7	LED Powerlink Controlled Node / Slave	
		10.1.8	LED PROFINET IO-RT Controller	
		10.1.9	LED PROFINET IO-RT-Device	
		10.1.10	LED SERCOS III Slave	
11	TECH	NICAL DAT	Α	68
	11.1	Technical	Data cifX Real-Time Ethernet Cards	68
		11.1.1	CIFX 50-RE	
		11.1.2	CIFX 50E-RE	
		11.1.3	CIFX 80-RE	
		11.1.4	CIFX 90-RE	71
		11.1.5	CIFX 104C-RE, CIFX 104C-RE-R, CIFX 104C-RE\F,	CIFX 104C-RE-R\F72
		11.1.6	AIFX-RE	
		11.1.7	AIFX-DIAG	73
	11.2	Protocols.		74
		11.2.1	EtherCAT Master	74
		11.2.2	EtherCAT Slave	74
		11.2.3	EtherNet/IP Scanner (Master)	75
		11.2.4	EtherNet/IP Adapter (Slave)	
		11.2.5	Open Modbus/TCP	
		11.2.6	Powerlink Controlled Node / Slave	77
		11.2.7	PROFINET IO-RT-Controller	
		11.2.8	PROFINET IO-RT-Device	79
		11.2.9	SERCOS III Slave	80
10				04
12	CONF			
		12.1.1	EtherCAT Slave Parameters	
		12.1.2	EtherNet/IP Adapter Parameters	
		12.1.3	Open Modbus/TCP Parameters	
		12.1.4	Powerlink Controlled Node / Slave Parameters	
		12.1.5	PROFINE I IO-Device Parameters	
		12.1.6	SERCOS III Slave Parameters	
13	LISTS			
	13.1	List of Fig	Ires	۹۵ ۵۵

Con	nmunica	Table of Contents • 5	
	13.2	List of Tables	91
14	GLOS	SARY	93
15	CONT	TACTS	94

1 Introduction

1.1 About the User Manual

This user manual contains descriptions of the installation, operation and hardware of Real Time Ethernet cifX cards under Windows [®] 2000/Windows[®].

1.1.1 List of Revisions

Index	Date	Chapter	Revisions
1	17 May 2006	all	created
2	13 June 2007	2, 4, 7 1, 3, 4, 7, 8	actualized according to ANSI Z 535.6, LED description actualized Descriptions for the cards CIFX 50E-RE, CIFX 90-RE, CIFX 104C-RE, CIFX 104C-RE-R, CIFX 104C-RE\F, CIFX 104C-RE-R\F completed, Descriptions for SERCOS III Slave added
3	27.06.07	7.1.3	Description MS and NS LED EtherNet/IP Adapter (Slave) adapted
4	01.08.07	all 3.4 – 3.11	EtherCAT Master, EtherNet/IP Scanner (Master) added, Notice to LED at RJ45 socket added
5	15.08.07	1.2, 1.3, 1.8, 3.1, 3.3, 5.1, 6 1.8 2.1., 7.1.1, 8.1, 8.2.1, 8.2.2 8.2.3	Information and description to the System configurator SYCON.net added, Information for Master license added, Information for PROFINET IO-RT-Controller added, Protocol data for EtherCAT-Master added.
6	15.02.08	All 1 2.1 2.4 3 4 5.4 6 7 8 9.1.1 9.1.2 10.2	Descriptions, data and drawings for the CIFX 80-RE card Descriptions Chapter "Introduction" actualized, Section "Intended Use" actualized, Section "Safety Instructions" actualized, Chapter "Description and Requirements" adapted, Chapter "Getting Startet" added, Section "CIFX 104C-RE and CIFX 104C-RE-R" adapted, Chapter "Installing Software" descriptions to the cifX Device Driver and cifX Driver Setup inserted, Chapter "Troubleshooting "actualized, Chapter "Device Drawings and Connections" here inserted and actualized, Section "LED PROFINET IO-RT Controller" adapted. Section " LEDs PROFINET IO-RT-Device " actualized. Section "Protocols" actualized,
7	05.05.08	All 1 2.1 3 4 5 6 7 11 12 14	Descriptions for Powerlink, Open Modbus/TCP and SERCOS III Slave added; Descriptions to the cifX Driver Setup erased, Descriptions to the netX Configuration and Diagnostic Utility inserted, Chapte "Introductionl" actualized, Section "Intended Use" actualized, Chapter "Description and Requirements" actualized, Chapter "Getting startet" actualized, Chapter "Installing CIFX Cards" actualized, Chapter "Installing Software" actualized, Chapter "Installing Software" actualized, Chapter "netX Configuration and Diagnostic Utility" added and actualized. Chapter "Technical Data" actualized, Chapter "Configuration Parameter" added and actualized. Glossary added
8	21.05.08	1 3 4 5 6 7 10	Chapte "Introductionl" actualized, Chapter "Description and Requirements" actualized, Chapter "Getting startet" actualized, Chapter "Installing CIFX Cards" actualized, Chapter "Installing Software" actualized, Chapter "netX Configuration and Diagnostic Utility" added and actualized. Chapter "LED" actualized
9	09.06.08	4.2 9.11.3 10.1.7 11.2 12	Section "Steps how to install and configure cifX Master Devices" actualized, Section "Use of Hubs and Switches" actualized, Section "LED Powerlink Controlled Node / Slave" actualized, Section "Protocols" actualized, Configuration parameters Real-Time-Ethernet-Systems actualized.,

Table 1: List of Revisions

1.1.2 Reference on Hardware and Software

Card Type	Device
CIFX 50-RE	Revision 2
CIFX 50E-RE	Revision 1
CIFX 80-RE	Revision 1
CIFX 90-RE	Revision 2
CIFX 104C-RE	Revision 3
CIFX 104C-RE-R	Revision 3
CIFX 104C-RE\F	Revision 3
CIFX 104C-RE-R\F	Revision 3
AIFX-RE	Revision 2
AIFX-DIAG	Revision 1

Table 2: Reference on Hardware

Software

Software	Software Version
netX Configuration and Diagnostic Utility-Setup:	
netXSetup.exe	1.1.0.49

Table 3: Reference on Software

1.1.3 Conventions in this Manual

Operating Instructions, a result of an operation step or notes are marked as follows:

Operating Instructions:

<instruction>

Or

- 1. <instruction>
- 2. <instruction>

Results:

P⇒ <result>

Notes:



Note: <note>

1.2 Contents of the Product CD

The Product CD for the Communication InterFaces cifX contains:

- cifX Device Driver
- netX Configuration and Diagnostic Utility setup including the loadable Firmware
- System configurator SYCON.net
- Device Description Files (GSDML, EDS, XML, XDD)
- Documentation

1.2.1 Directory Structure of the CD

All manuals on this CD are delivered in the Adobe Acrobat[®] Reader format (PDF).

Directory Name	Description
API	Toolkit, Header Files and cifX32DLL.lib
Documentation	Documentation in the Acrobat [®] Reader Format (PDF)
Driver	cifX Device Driver
EDS	Device Description File
Firmware	Loadable Firmware
Software	cifX Configuration and Diagnostic Utility, System Configurator SYCON.net (configuration and diagnostic program)

Table 4: Directory Structure of the CD

1.2.1.1 Device Description Files

The CD Rom includes the device description files for the following Slave devices:

Real Time Ethernet	Name / Extension
EtherCAT Slave	DDF, XML
EtherNet/IP Adapter (Slave)	EDS
Powerlink Controlled Node / Slave	XDD
PROFINET IO-RT-Device	GSDML/XML

Table 5: Device Description Files

1.2.2 Documentations cifX Cards

The following documentation overview gives information, for which items you can find further information in which manual.

Manual	Contents	Document name
User Manual, CIFX Cards Real Time Ethernet	Installation, Operation and Hardware Description	CIFX-RE_usermanual_en.pdf
Operating Instruction Manual	SYCON.net Frame Application	SYCONnet_netFrame_en.pdf
Operating Instruction Manual	FDT Container	SYCONnet_netDevice_en.pdf
Operating Instruction Manual	DTM for EtherCAT Master	EtherCAT_Master_DTM_en.pdf*
Operating Instruction Manual	Generic EtherCAT Slave DTM for EtherCAT Slave Devices	EtherCAT_Slave_DTM_en.pdf*
Operating Instruction Manual	DTM for EtherNet/IP Scanner Devices	EtherNetIP_Scanner_DTM_en.pdf
Operating Instruction Manual	DTM for EtherNet/IP Adapter Devices	EtherNetIP_Adapter_DTM_en.pdf
Operating Instruction Manual	Generic EtherNet/IP Adapter DTM for EtherNet/IP Adapter Devices and Modular Generic EtherNet/IP Adapter DTM for modular EtherNet/IP Adapter Devices	EtherNetIP_GenericAdapter_DTM_en.pdf
Operating Instruction Manual	DTM for Hilscher PROFINET IO-Controller	PROFINET_IO_Controller_DTM_en.pdf
Operating Instruction Manual	DTM for Hilscher PROFINET IO-Devices	PROFINET_IO_Device_DTM_en.pdf
Operating Instruction Manual	Generic DTM for PROFINET IO Devices	PROFINET_IO_GenericDevice_DTM_en.pdf

Table 6: Documentations cifX Devices Real Time Ethernet

1.3 Legal Notes

1.3.1 Guarantee

Although the cifX cards CIFX 50-RE, CIFX 50E-RE, CIFX 80-RE, CIFX 90-RE, the devices of the family CIFX 104C-RE and the AIFX-RE and AIFX-DIAG interfaces as well as the driver program have been developed with great care and has been thoroughly tested, Hilscher Gesellschaft für Systemautomation mbH cannot guarantee the suitability of these boards for any purpose not confirmed by us in writing.

Guarantee claims shall be limited to the right to require rectification. Liability for any damage which may have arisen from the use of this hard and software or its documentation shall be limited to cases of intent.

1.3.2 Registered Trademarks

 $\mathsf{Windows}^{\texttt{8}}$ 2000 / $\mathsf{Windows}^{\texttt{8}}$ XP $% \mathsf{A}$ are registered trademarks of Microsoft Corporation.

1.4 Licenses

If a cifX card is used as a slave, neither for the firmware nor for the configurator SYCON.net a license is required.

Licenses are required, if the cifX card is used with

- a firmware with master functionality*,
- an OPC server.

* The master license includes the card operating as master and the license for the configurator SYCON.net for the respective card.

2 Safety

2.1 Intended Use

The cifX cards

- CIFX 50-RE, CIFX 50E-RE
- CIFX 80-RE
- CIFX 90-RE
- CIFX 104C-RE, CIFX 104C-RE-R
- CIFX 104C-RE\F, CIFX 104C-RE-R\F

described in this user manual are PC cards for real-time Ethernet communication. Depending from the loaded firmware, the real time Ethernet systems listed hereafter can be realized using the cifX card:

- EtherCAT Master
- EtherCAT Slave
- EtherNet/IP Scanner (Master)
- EtherNet/IP Adapter (Slave)
- Open Modbus/TCP
- Powerlink Controlled Node / Slave
- PROFINET IO-RT-Controller
- PROFINET IO-RT-Device
- SERCOS III Slave

The interfaces

- AIFX-RE
- AIFX-DIAG

are used for connection to the CIFX 90-RE card or the devices of the family CIFX 104C-RE.

2.2 Personnel Qualification

The cifX card must only be installed, configured and removed by qualified personnel.

2.3 Labeling of Safety Instructions

The safety instructions are pinpointed particularly. The instructions are highlighted with a specific safety symbol, a warning triangle and a signal word according to the degree of endangerment. Inside the note the danger is exactly named. Instructions to a property damage message do not contain a warning triangle.

Symbol	Sort of Warning or Principle
	Safety symbol for the warning to personal injury
	Warning of danger by electrical current
	Warning of damages by electrostatic discharge

Table 7: Safety Symbols and Sort of Warning or Principle

2.3.1.1 Signal Words

Signal Word	Meaning
DANGER	indicates a direct hazard with high risk, which will have as consequence death or grievous bodily harm if it isn't avoided.
	The use of this signal word shall be restricted to extremely hazard.
	Remark: The signal word may not be used in case of danger of pure property damages.
WARNING indicates a possible hazard with medium risk, which will have as consequence death or (grievous) bodily harm if it isn't avoided.	
	Remark: The signal word may not be used in case of danger of pure property damages.
CAUTION	indicates a minor hazard with medium risk, which could have as consequence simple battery if it isn't avoided.
Note	Indicates an important note in the manual.

Table 8: Signal Words

2.3.1.2 Signal Words USA

Signal Word	Meaning
DANGER	Indicates a Hazardous Situation Which, if not Avoided, will Result in Death or Serious Injury.
WARNING	Indicates a Hazardous Situation Which, if not Avoided, could Result in Death or Serious Injury.
CAUTION	Indicates a Hazardous Situation Which, if not Avoided, may Result in Minor or Moderate Injury.
NOTICE	Indicates a Property Damage Message.
Note	Indicates an Important Note in the Manual.

Table 9: Signal Words according to ANSI

2.4 Safety Instructions

This manual contains instructions which must be observed to ensure your own personal safety and to avoid damage to devices.

2.4.1 Electrical Current



Electrocution

- Disconnect the power plug of the PC and make sure, that the PC is current-free.
- Only after disconnecting power open the PC cabinet and install or remove the cifX card.



Device Destruction!

Use only 3.3 V for power supply to operate the card.
 Operation with 5 V power supply leads to device destruction.
 Also all I/O signals are only 3.3V tolerant.

The cifX card may not be powered by a 5 V power supply! The cifX card may only be powered by a 3.3 V power supply. The use of a higher supply voltage than 3.3V may result in severe damage to the cifX card! Further, all signal pins require 3.3V signaling voltage and are not 5 V tolerant!

2.4.2 Electrostatic Discharge

Adhere to the necessary safety precautions for components that are vulnerable with electrostatic discharge (EN 61340-5-1 und EN 61340-5-2 as well as IEC 61340-5-1 und IEC 61340-5-2).



Electrostatic Discharge

CAUTION! This equipment is sensitive to electrostatic discharge, which cause internal damage and affect normal operation. Follow guidelines when you handle this equipment:

- Touch a grounded object to discharge potential static.
- Wear an approved grounding wriststrap.
- Do not touch connectors or pins on component boards.
- Do not touch circuit components inside the equipment.
- If available, use a static-safe workstation.
- When not in use, store the equipment in appropriate static-safe packaging.

2.5 Safety Instructions USA

This manual contains instructions which must be observed to ensure your own personal safety and to avoid damage to devices.

2.5.1 Electrical Current



ACAUTION

Electrocution

- Disconnect the power plug of the PC and make sure, that the PC is current-free.
- Only after disconnecting power open the PC cabinet and install or remove the cifX card.



NOTICE

Device Destruction!

 Use only 3.3 V for power supply to operate the card. Operation with 5 V power supply leads to device destruction. Also all I/O signals are only 3.3V tolerant.

The cifX card may not be powered by a 5 V power supply! The cifX card may only be powered by a 3.3 V power supply. The use of a higher supply voltage than 3.3V may result in severe damage to the cifX card! Further, all signal pins require 3.3V signaling voltage and are not 5 V tolerant!

2.5.2 Electrostatic Discharge

Adhere to the necessary safety precautions for components that are vulnerable with electrostatic discharge (EN 61340-5-1 und EN 61340-5-2 as well as IEC 61340-5-1 und IEC 61340-5-2).



NOTICE

Electrostatic Discharge

This equipment is sensitive to electrostatic discharge, which cause internal damage and affect normal operation. Follow guidelines when you handle this equipment:

- Touch a grounded object to discharge potential static.
- Wear an approved grounding wriststrap.
- Do not touch connectors or pins on component boards.
- Do not touch circuit components inside the equipment.
- If available, use a static-safe workstation.
- When not in use, store the equipment in appropriate static-safe packaging.

3 Description and Requirements

3.1 Description

The cifX devices described in this user manual are PC cards for real-time Ethernet communication. Depending of the loaded firmware, the cifX card proceeds the communication of one of the following real time Ethernet systems:

- EtherCAT Master
- EtherCAT Slave
- EtherNet/IP Scanner (Master)
- EtherNet/IP Adapter (Slave)
- Open Modbus/TCP
- Powerlink Controlled Node / Slave
- PROFINET IO-RT-Controller
- PROFINET IO-RT-Device
- SERCOS III Slave

The cifX handles the complete data exchange between the connected Ethernet devices and the PC. The data exchange is proceeded via dual-port memory.

3.2 System Requirements

- 1. Windows[®] 2000 / Windows[®] XP
- 2. PC with PCI connector (3.3 V)

Type of Card	PCI Connector
CIFX 50-RE	PCI slot (3,3 V)
CIFX 50E-RE	PCI Express X1 slot (3,3 V),
	X1 = Single Lane
CIFX 80-RE	Compact PCI (3,3 V)
CIFX 90-RE	Mini PCI Socket (3,3 V), Type III System Connector
CIFX 104C-RE	PCI Slot for PC/104 cards (3,3 V)
CIFX 104C-RE-R	
CIFX 104C-RE\F	
CIFX 104C-RE-R\F	

Table 10: PCI Connector for cifX cards

- 3. CD ROM drive
- 4. Graphic resolution: min. 1024 x 768 pixel or higher
- 5. Keyboard and Mouse

3.3 Requirements for Operation

3.3.1 cifX Slave Device

For cifX Slave device operation the following requirements must be fulfilled:

Protocols	EtherCAT-Slave, EtherNet/IP-Adapter (Slave), Open Modbus/TCP, Powerlink Controlled Node / Slave, PROFINET IO-Device, SERCOS III-Slave
Software	1. The cifX Device Driver must be installed (from V0.933).
Installation	2. The netX Configuration and Diagnostic Utility program must be installed.
Firmware- Download	3. Using the netX Configuration and Diagnostic Utility program, the user must select the firmware which is to be loaded to the cifX Slave device.
Parameter Setting	4. The cifX Slave device must be parameterized using one of the following options:
	 netX Configuration and Diagnostic Utility program
	 Application program (programming required)
Communication	5. For the communication a Master for the respective communication system is required.

Table 11: Requirements for cifX Slave Device Operation

3.3.2 cifX Master Device

For cifX Master device operation the following requirements must be fulfilled:

Protocols	EtherCAT-Master, EtherNet/IP-Scanner (Master), PROFINET IO-Controller
Software Installation	1. The cifX Device Driver must be installed (from V0.933).
Firmware- Download	3. Using the system configurator SYCON.net , the user must select the firmware which is to be loaded to the cifX Master device.
Configuration	4. The cifX Master device must be configured using one of the following options:
	System configurator SYCON.net
	 Application program (programming required)
Communication	For communication slave devices for the used communcation system are required.

Table 12: Preconditions for cifX Master Device Operation

4 Getting Startet

4.1 Steps how to install and configure cifX Slave Devices

The following table describes the steps to configure a cifX Slave device as it is typical for many cases.

#	Step	Description	For detailed information see section	Page
1	Hardware Installation	vare Installation Installing cifX Slave device:		21
		Disconnect the power plug of the PC.		
		Open the cabinet of the PC.		
		If necessary, glue enclosed sticker on the front plate.		
		Plug in and mount the cifX Slave device.		
		If necessary, connect a connection or a diagnosis interface.		
		Close the PC casing.		
		Connect the PC to the power supply and switch on the PC.		
2	cifX Device Driver Installation	Windows [®] recognizes a new hardware and requires the device driver, which is on the CD-ROM cifX.	Installing cifX Device Driver	28
		Enter the CD-ROM cifX in the PC and follow to the instructions of the installation wizard, to install the driver.		
3	netX Configuration and Diagnostic Utility Installation	Start the netX Utility setup program to install the netX Configuration and Diagnostic Utility .	Installing the netX Configuration and Diagnostic Utility	33
4	Setting cifX Slave Device Parameters	In the netX Configuration and Diagnostic Utility : - Select the language, - Select and download the firmware, - Setting the cifX Slave Device parameters.	Configuration Steps cifX Card	34

Table 13: Installation and Configuration Steps cifX Slave Device

4.2 Steps how to install and configure cifX Master Devices

The following table describes the steps to configure a cifX Master device as
it is typical for many cases.

#	Step	Description	For detailed information see section	Page
1	Hardware Installation	ardware Installation Installing cifX Master device:		21
		Disconnect the power plug of the PC.		
		Open the cabinet of the PC.		
		If necessary, glue enclosed sticker on the front plate.		
		Plug in and mount the cifX Master device.		
		If necessary, connect a connection or a diagnosis interface.		
		Close the PC casing.		
		Connect the PC to the power supply and switch on the PC.		
2	cifX Device Driver Installation	Windows [®] recognizes a new hardware and requires the device driver, which is on the CD-ROM cifX.	Installing cifX Device Driver	28
		Enter the CD-ROM cifX in the PC and follow to the instructions of the installation wizard.		
3	SYCON.net Installation	Run the SYCON.net-Setup.	Installing SYCON.net	33
4	Firmware Download	 Start system configurator SYCON.net. Select driver and assign device. Select and download the firmware. 	See corresponding user manual under Documentations cifX Cards	10
5	Configuration cifX Master device	- Configure the cifX Master device.		
6	Download Configuration	- Download the configuration to the cifX Master device *. (*EtherCAT-Master, EtherNet/IP-Scanner (Master), PROFINET IO-Controller)		
7	Diagnostic	 Righclick on device symbol. Select context menu entry Diagnosis, then select Diagnosis > Station Diagnosis or Master Diagnosis. 		
8	I/O Monitor	 Righclick on device symbol. Select context menu entry Diagnosis, then Additional Tools > IO Monitor. Check the input or output data. 		

Table 14: Installation and Configuration Steps cifX Master Device

5 Installing cifX Card

5.1 Safety Advices

Obey to the following safety advices, when installing the cifX card.



Electrocution

- Disconnect the power plug of the PC and make sure, that the PC is current-free.
- Only after disconnecting power open the PC cabinet and install or remove the cifX card.



Device Destruction!

Use only 3.3 V for power supply to operate the card.
 Operation with 5 V power supply leads to device destruction.

CAUTION!





 To prevent damage to the PC and the cifX, make sure, that the cifX card is grounded via the endplate and the PC and make sure, that you are discharged when you mount/demount the cifX card.

5.1.1 Safety Advices USA

Obey to the following safety advices, when installing the cifX card.



Electrocution

- Disconnect the power plug of the PC and make sure, that the PC is current-free.
- Only after disconnecting power open the PC cabinet and install or remove the cifX card.



NOTICE

Device Destruction!

 Use only 3.3 V for power supply to operate the card. Operation with 5 V power supply leads to device destruction. Also all I/O signals are only 3.3V tolerant.



NOTICE

Damage from electrostatic Discharge

 To prevent damage to the PC and the cifX, make sure, that the cifX card is grounded via the endplate and the PC and make sure, that you are discharged when you mount/demount the cifX card.

5.2 CIFX 50-RE and CIFX 50E-RE

For installation of the CIFX 50-RE or CIFX 50E-RE card handle as follows:

- 1. Use the sticker according to the firmware and glew it on the front of the CIFX 50-RE or CIFX 50E-RE card (see section *Fix Front Plate Sticker* on page 23).
- 2. Disconnect the power plug of the PC.
- 3. Open the cabinet of the PC.
- 4. Plug in the CIFX 50-RE card on a free PCI slot, or plug in the CIFX 50E-RE card on a free PCI express slot.
- 5. Fix the CIFX 50-RE or CIFX 50E-RE card using the hole intended.
- 6. Close the PC casing.
- 7. Connect the PC to the power supply and switch on the PC.

5.2.1 Fix Front Plate Sticker

\rightarrow

Note: Your cifX card set contains a set of front plate stickers (6 different stickers). Depending from the loaded firmware the label on each sticker indicates the names of the respective system and communication status LED or of the LED of the RJ45 Ethernet female connector. (Further information to this question you find also in section *LED Real Time Ethernet Systems* beginning from page 58.)

Front Plate Stickers for CIFX 50-RE and CIFX 50E-RE:



Figure 1: Front Plate Stickers for CIFX 50-RE and CIFX 50E-RE for the labeling of the card LED or of the LED of the Ethernet female connector

cifX-LE	D	EtherCAT Master	EtherCAT Slave	EtherNet/IP	Powerlink	Open Modbus/TCP	PROFINET IO	SERCOS III
SYS (yellow / green)		SYS	SYS	SYS	SYS	SYS	SYS	SYS
COM 0 (red/ green)		RUN	RUN	MS	BS	RUN	SF	STA
COM 2 (red/ green)		ERR	ERR	NS	BE	ERR	BF	ERR
RJ45	green	LINK	L/A IN	LINK	L/A	LINK	LINK	L/A
Chu	yellow	ACT	-	ACT	-	ACT	RX/TX	-
RJ45	green	-	L/A OUT	LINK	L/A	LINK	LINK	L/A
Cn1	yellow	-	-	ACT	-	ACT	RX/TX	-

Table 15: cifX LED Labeling depending of the loaded Firmware

Use the sticker according to the firmware and glew it on the front of the CIFX 50-RE or CIFX 50E-RE card.

5.3 CIFX 80-RE

For installation of the CIFX 80-RE card handle as follows:

- 1. Use the sticker according to the firmware and glew it on the front of the CIFX 80-RE card (see section *Fix Front Plate Sticker* on page 25).
- 2. Disconnect the power plug of the PC.
- 3. Open the cabinet of the PC and remove blank plate.
- 4. Put down the ejection lever at the CIFX 80-RE card.
- 5. Plug in the CIFX 80-RE card to a free compact PCI slot.
- 6. Fasten the CIFX 80-RE card.
- ➢ Tip up the lever and click in.
- Screw the CIFX 80-RE card with two screws onto the wholes above and below.
- 7. Close the PC casing.
- 8. Connect the PC to the power supply and switch on the PC.

Note: To remove the CIFX 80-RE card from the compact PCI slot, first press the grey button at the ejection lever and then press the ejection lever downwards.

5.3.1 Fix Front Plate Sticker

Note: Your cifX card set contains a set of front plate stickers (6 different stickers). Depending from the loaded firmware the label on each sticker indicates the names of the respective system and communication status LED or of the LED of the RJ45 Ethernet female connector. (Further information to this question you find also in section *LED Real Time Ethernet Systems* beginning from page 58.)

cifX-LE	D	EtherCAT Master	EtherCAT Slave	Ether Net/IP	Powerlink	Open Modbus/TCP	PROFINET IO	SERCOS III
SYS (yellow / green)		SYS	SYS	SYS	SYS	SYS	SYS	SYS
COM 0 (red/ green)		RUN	RUN	MS	BS	RUN	SF	STA
COM 1 (red/ green)		ERR	ERR	NS	BE	ERR	BF	ERR
RJ45	green	LINK	L/A IN	LINK	L/A	LINK	LINK	L/A
Chu	yellow	ACT	-	ACT	-	ACT	RX/TX	-
RJ45 Ch1	green	-	L/A OUT	LINK	L/A	LINK	LINK	L/A
	yellow	-	-	ACT	-	ACT	RX/TX	-

Table 16: cifX LED Labeling depending of the loaded Firmware

Use the sticker according to the firmware and glew it on the front of the CIFX 80-RE card.

5.4 CIFX 90-RE

For installation of the CIFX 90-RE card handle as follows:

- 1. Disconnect the power plug of the PC.
- 2. Open the cabinet of the PC.
- 3. Plug in the CIFX 90-RE card in the Mini PCI socket (Type III System Connector) on the mainboard.
- 4. Press the clamps at the Mini PCI socket until they snap in, to fasten the CIFX 90-RE card to the mainboard.

To connect the AIFX-RE connection interface:

- 5. Connect the cable connector X1 on the AIFX-RE connection interface with the cable.
- 6. Connect the cable connector X4 on the CIFX 90-RE card with the cable.
- 7. Mount the AIFX-RE on the PC cabinet.

Only then:

- 8. Close the PC casing.
- 9. Connect the PC to the power supply and switch on the PC.

5.5 CIFX 104C-RE and CIFX 104C-RE-R

For installation of the CIFX 104C-RE card handle as follows:

- 1. Disconnect the power plug of the PC.
- 2. Open the cabinet of the PC.
- 3. Plug in the CIFX 104C-RE card on a free PCI slot for PC 104 cards.
- 4. Fix the CIFX 104C-RE card to the mainboard using 4 spacing bolts and screws intended. The scope of delivery does not include spacing bolts and screws.
- 5. Close the PC casing.
- 6. Connect the PC to the power supply and switch on the PC.

5.6 CIFX 104C-RE\F and CIFX 104C-RE-R\F

For installation of the CIFX 104C-RE card handle as follows:

- 1. Disconnect the power plug of the PC.
- 2. Open the cabinet of the PC.
- 3. Plug in the CIFX 104C-RE card on a free PCI slot for PC 104 cards.
- 4. Fix the CIFX 104C-RE card to the mainboard using 4 spacing bolts and screws intended. The scope of delivery does not include spacing bolts and screws.

To connect the connection interface AIFX-RE:

- 5. Connect the cable connector Ethernet X 1 on the connection interface AIFX-RE with the cable.
- 6. Connect the cable connector Ethernet X 4 (or X304) on the CIFX 104C-RE card with the cable.
- 7. Mount the AIFX-RE on the PC cabinet.

To connect the Diagnosis Interface AIFX-DIAG:

- 8. Connect the cable connector DIAG X 1 on the Diagnosis Interface AIFX-DIAG with the cable.
- 9. Connect the cable connector DIAG X 3 (or X303) on the CIFX 104C-RE card with the cable.
- 10. Mount the AIFX-DIAG on the PC cabinet.

After that:

- 11. Close the PC casing.
- 12. Connect the PC to the power supply and switch on the PC.

6 Installing Software

6.1 Installing cifX Device Driver

To install the cifX Device Driver proceed as described hereafter:

1. After installation of the cifX card restart your PC.

Windows[®] 2000 / Windows[®] XP recognize the cifX card automatically.

- ✤ The message Found New Hardware is displayed and the Found new Hardware Wizard is started.
- 2. Select Install from a list or specific location (Advanced).

Found New Hardware Wizard					
	Welcome to the Found New Hardware Wizard				
	This wizard helps you install software for:				
	PCI Device				
	If your hardware came with an installation CD or floppy disk, insert it now. What do you want the wizard to do?				
	Install the software automatically (Recommended)				
	Install from a list or specific location (Advanced)				
	ick Next to continue.				
	< <u>B</u> ack <u>N</u> ext > Cancel				

Figure 2: Found new Hardware Wizard - Indicate Software Source

- 3. Insert the installation CD now.
- 4. Click to the button **Next >**.
- ✤ The Found new Hardware Wizard asks you to select the researchand installation options.

Found New Hardware Wizard
Please choose your search and installation options.
Search for the best driver in these locations.
Use the check boxes below to limit or expand the default search, which includes local paths and removable media. The best driver found will be installed.
Search removable media (floppy, CD-ROM)
Include this location in the search:
D:\ Browse
O Don't search. I will choose the driver to install.
Choose this option to select the device driver from a list. Windows does not guarantee that the driver you choose will be the best match for your hardware.
< <u>B</u> ack <u>N</u> ext > Cancel

Figure 3: Found new Hardware Wizard - Select research- and installation options

- 5. Select Search for the best driver in these locations.
- 6. Activate the checkbox Search removable media (floppy, CD-ROM...).
- 7. Click to the button **Next >**.
- [™] The driver software for the **cifX Device Driver** gets installed.



Figure 4: Found new Hardware Wizard - Software gets installed

✤ The Found new Hardware Wizard indicates the cifX PCI/PCIe Device software installation is complete.



Figure 5: Found new Hardware Wizard - Software installation has been completed

- 8. Click in Found new Hardware Wizard > Completing the Found new Hardware Wizard to the button Finish.
- [№] The installation of the **cifX Device Driver** is complete.

- 9. Check in the **Computer Manager**, if your cifX card installed correctly.
- Therefore open the Computer Manager as follows: Desktop symbol My Computer > rightclick Properties > window System Properties > tab Hardware > button Computer Manager.
- Check, if the view of your Computer Manager corresponds to the marked area in the view hereafter.

🖳 Computer Management	×
🗐 Eile Action View Window Help	
SOFTWARE_15 SOFTWARE_15 Audio-, Video- und Gamecontroller CIF Communication Interface CIF× COM CIF× COM CIF× CIF× CIF× CIF× CIF× CIF× CIF× CIF×	
Hoppy disk controllers Floppy disk drives JVD/CD-ROM drives Just drives Just drives IDE ATA/ATAPI controllers Disk drives	~

Figure 6: Device Manager > cifXPCI/PCIe Device - correctly installed



Note: The cifX card has to be configured.

6.2 Installing the netX Configuration and Diagnostic Utility

After the **cifX Device Driver** is installed start the netX Utility setup program to install the **netX Configuration and Diagnostic Utility**:

Therefore:

- > Close all application programs on the system!
- > Insert the cifX CD to the local CD ROM drive.
- Start in the directory Software the netX Utility setup program and execute the installation steps according to the instructions at the screen.
- Or:
- Select netX Configuration and Diagnostic Utility of the autostart menu.

6.3 Installing SYCON.net

To install the system configurator SYCON.net:

- > Close all application programs on the system!
- > Insert the cifX CD to the local CD ROM drive.
- Start in the directory Software the SYCON.net setup program SYCONnet netX setup.exe.

Or:

> Select SYCON.net of the autostart menu.



Note: Administrator privileges are required on Windows[®] 2000/ Windows[®] XP systems for installation!

- > Choose **System Installation** from the start screen.
- ♣ The installation program asks for the components to be installed.
- > Answer these questions with **Yes** or **No**.

7 netX Configuration and Diagnostic Utility

7.1 Configuration Steps cifX Card

The chapter **netX Configuration and Diagnostic Utility** provides information on how to configure the device parameters of a real-time Ethernet or a fieldbus Slave and what can be read from the diagnostic window.

Configuration Steps

The following table describes the main steps how to configure a cifX device if the cifX device driver is already installed.

#	Action	Short Description	For detailed information see section	Page
1	Starting the netX Utility	Start the netX Configuration and Diagnostic Utility.	Starting netX Configuration and Diagnostic Utility	35
2	Selecting the Language	Select the language of the netX Configuration and Diagnostic Utility graphical user interface.	Selecting Language / Firmware, downloading Firmware	40
3	Selecting the Firmware Protocol and downloading the Firmware	Select the firmware protocol. Download the firmware via Apply .	Selecting Language / Firmware, downloading Firmware	40
4	Set and download the Parameters	Set the configuration parameters for the Slave to be used and download this one to the cifX card.	Configuration	41
5	cifX Diagnosis	Check cifX communication.	Diagnostics	43

Table 17: Configuration Steps / USB Device Driver already installed

7.2 Starting netX Configuration and Diagnostic Utility

- Start the netX Configuration and Diagnostic Utility via Start > Programs > netX Setup > netX Setup Program.
- ✤ The utility detects the type of the connected cifX, for Real-Time-Ethernet or for fieldbusses.

To read more on how to configure the cifX and to use its diagnostic features refer to the descriptions hereafter.

7.3 Introduction to the Dialog Structure

The graphical user interface of the **netX Configuration and Diagnostic Utility** is divided in five main areas:

- A header with the Select Network and Language Bar
- A second header with the **Device Identification**
- The Navigation Area (left side)
- The Configuration Window (middle)
- The Diagnostic Window (right side)



Figure 7: Dialog Structure of netX Configuration and Diagnostic Utility

Additional information e. g. online-state of the **netX Configuration and Diagnostic Utility** can be found in the **Status Line**.

Explanations to general dialog elements like buttons can be found in the subsection *General Buttons* on page 37.

Select Network / Language Icon Bar





Figure 9: Select Language Icon Bar (only English yet)

Device Identification

The **Device Identification** shows the information about the connected cifX.

Parameter	Meaning	
IO Device	Name of the device	
Vendor	Vendor name of the device	
Firmware	Name of the currently loaded firmware	
Device ID	Identification number of the device	
Vendor ID	Identification number of the vendor	
Version	Version of the currently loaded firmware	

Table 18: Device Identification

Navigation Area, Configuration and Diagnostic Window

The Navigation Area at the left side of the netX Configuration and Diagnostic Utility shows the installed drivers and devices as a folder structure. The Navigation Area can be hidden via the symbol \times or it can be displayed again via the symbol \square .

The actual parameters of the currently loaded firmware are displayed in the **Configuration** window of the **netX Configuration and Diagnostic Utility** and can be edited there.

In the **Diagnostic** window system and communication diagnosis is displayed. With the **Start COM** button the communication to the Master can be started respectively can be stopped with the **Stop COM** button. The device can also be reset with the **Reset** button.
7.3.1 General Buttons

The table below explains the general buttons in the **netX Configuration** and **Diagnostic Utility** user interface.

Button	Meaning
ок	1. Configuration modified - The firmware and Configuration are downloaded: If the configuration has been changed and you click to the OK button, the firmware/configuration is downloaded to the cifX.
	2. Configuration has not been modified - If the configuration has not been changed and you click to the OK button, you are asked if you want to download the firmware/configuration, if you want to quit the netX Configuration and Diagnostic Utility or if you want to cancel.
Cancel	If the configuration has been changed and you click to the Cancel button, you are asked if you want to save the configuration. If you answer this question with yes, the configuration will be saved but it will not been downloaded to the cifX.
Apply	If the configuration has been changed and you click to the Apply button, the firmware/configuration is directly downloaded to the cifX and the Apply button is greyed out again.
	The Apply button is greyed out, if the offline and the online configuration are identical.
Help	To open the netX Configuration and Diagnostic Utility online help, click on the Help button.

Table 19: General Buttons

7.3.2 Help

To open the help in netX Configuration and Diagnostic Utility, click on the Help button or press the F1 key.

7.3.3 Status Line

The **Status Line** displays information about the current state of the netX Configuration and Diagnostic Utility. The download or any other activity is signaled in the status line.



Figure 10: Status Line – Status Fields 1 to 6

Number	Meaning	lcon
1	Connection State:	
	Icon going closed = Device is going online	35
	Icon closed = Device is online	-1-
	Icon going opened = Device is going offline	\Leftrightarrow
	Icon opened = Device is offline	
	Icon with lightening = Device communication disturbed	~
2	Data Source States	
	The displayed data are read out from the instance data set (database).	
	The displayed data are read out from the instance data set (database). Database is locked with password.	P
	The displayed data are read out from the device.	
	The displayed data are read out from the device. Device is locked with password.	
3	States of the instance Data Set	
	All data loaded	-
	Valid Modified = Parameter is changed (not equal) to data source.	/
	Invalid Modified = Invalid value (e. g. not plausible)	ļ
	Initial data set = Parameter value is equal to data source value (data base or fieldbus device).	-
4	Changes directly made on the Device	
	Changes have only an impact on the device and not on the instance data set. Instance data set and device may not be consistent any more.	
	Load Configure and Diagnosis Parameters	8

Table 20: Status Line Icons

7.4 Working with netX Configuration and Diagnostic Utility

After the **netX Configuration and Diagnostic Utility** has been started, the **Select Network / Language Icon Bar** is activated. All the other firmware / language buttons are greyed out. The **Device Identification** shows the information about the connected cifX.

- man - same a second	
ID Device: citX0 Device ID: 0 Firmware: - Vendor: Hilscher GmbH Vendor ID: 1 Version: -	
Kavigation X Configuration Diagnostic	Help
الله المعطي المعلم ا	V1.1.0.33

Figure 11: netX Configuration and Diagnostic Utility

7.4.1 Selecting Language / Firmware, downloading Firmware

1. In the **Select Language Icon Bar** select the language icon for the language in which the graphical user interface shall be displayed.

lcon	Language
***	English
	Japanese
	Italian
	French
	German
6 ,5	Chinese

Table 21: Select Language Icon Bar (only English yet)

- ✤ The graphical user interface of the netX Configuration and Diagnostic Utility is displayed in the corresponding language.
- 2. Selecting Firmware Protocol.

Real-Time Ethernet	
Firmware Button	Firmware
EtherNet/IP>	EtherNet/IP-Adapter (Slave)
POWERLINK	Powerlink Controlled Node / Slave
	PROFINET IO-Device
Ether CAT.	EtherCAT-Slave
III SERCOS	SERCOS III Slave
Modbus-IDA	Open Modbus/TCP

Fieldbus	
Firmware Button	Firmware
00000	PROFIBUS DP-Slave
CC-Link	CC-Link Slave
DeviceNet	DeviceNet Slave
CANopen	CANopen Slave

Table 22: Select Network Icon Bar: Firmware Buttons Real-Time Ethernet and Fieldbus System

- Select in the Select Network Icon Bar the firmware button for the Slave device you intend to use with the cifX.
- 3. Set parameters.
- 4. Download Firmware.
- Activate the Apply button.
- ✤ The selected firmware/configuration is directly downloaded to the cifX device. The download is signaled in the status line.

7.4.2 Configuration

The actual parameters of the selected firmware protocol are displayed in the **Configuration** window. The configuration parameters can be edited. With the **Default** button the parameters can be reset to the default state.

> Click to the **Configuration** window to put the focus on it.



Figure 12: Configuration Window



Note: For the description of the single parameters refer to section *Fehler! Verweisquelle konnte nicht gefunden werden.* on page Fehler! Textmarke nicht definiert..

Section	Subsection	Manual Page
Fehler!	EtherCAT Slave Parameters	81
Verweisquelle konnte nicht	EtherNet/IP Adapter Parameters	82
gefunden werden.	Open Modbus/TCP Parameters	84
	Powerlink Controlled Node / Slave Parameters	86
	PROFINET IO-Device Parameters	88
	SERCOS III Slave Parameters	89

T able 23: Descriptions Configuration Windows

7.4.3 Diagnostics

The **Diagnostic** window displays:

- System and Communicating status information,
- 16 Bit Input / Output data,
- the SYS and COM LED status,
- and the buttons for the functions: **Start COM** Start Communication, **Stop COM** Stop Communication and **Reset** Reset Device.
- > Click to the **Diagnostic** window to put the focus on it.

	Diagnostic	
System		
Ready:	0	
Error:		
Change of State:	0x80000000	
State:	0x00000000	
Error Code:	0x0000000	
Communication		
Communicating:	٢	
Error:		
Change of State:	0x00000007	
State:	0x00000002	
Error Code:	0x0000000	
 SYS COM 15 14 13 12 11 10 9 5 SYS 15 14 13 12 11 10 9 5 	Input 7 6 5 4 3 2 1 0 Output 3 7 6 5 4 3 2 1 0 8 7 6 5 4 3 2 1 0	Start COM Stop COM

Figure 13: Diagnostic Window

7.4.3.1 Diagnostic: System

System	
Ready:	•
Error:	
Change of State:	0×80000000
State:	0×00000000
Error:	0×00000000

Figure 14: Diagnostic Window > System

Display	Meaning
Ready	Indicates, that the firmware has been started correctly. The firmware waits for a configuration.
Error end{tabular}	Indicates, that the firmware reports an error.
Change of State	The system change of state field contains information of the current operating status of the communication channel.
State	The system status field holds information regarding netX operating system rcX. The value indicates the current state the rcX has.
Error	The system error field holds information about the general status of the netX firmware stacks. An error code of zero indicates a faultless system.

Table 24: Diagnostic Window > System

7.4.3.2 Diagnostic: Communication

Communication	
Communicating:	
Error:	
Change of State:	0x0000007
State:	0x00000002
Error Code:	0x00000000

Figure 15: Diagnostic Window > Communication

Display	Meaning
Communicating	Indicates, that the cifX takes part in the network communication.
Error	Indicates, that the firmware reports an error.
Change of State	The communication change of state register contains information about the current operating status of the communication channel and its firmware.
State	The communication state field contains information regarding the current network status of the communication channel.
Error	This field holds the current error code of the communication channel. If the cause of error is resolved, the communication error field is set to zero again.

Table 25: Diagnostic Window > System, Communication

7.4.3.3 Diagnostic: Input / Output, SYS / COM

Input / Output

Under **Input / Output** the state of the respective input or output signal is displayed for the first two Byte of the transmitted data.

- > To set the inputs, click to the corresponding input symbol.
- ♣ The input symbol is displayed in the corresponding color.

If the Master sends data, the outputs are set.



Figure 16: Diagnostic Window > Input, Output, Start COM, Stop COM, Reset

<u>SYS/COM</u>

Under SYS / COM the state of the respective LED is displayed.

Further information to this you find in section *LED Real Time Ethernet Systems* beginning from page 58

7.4.3.4 Diagnostic: Start COM, Stop COM, Reset

Button	Meaning
Start COM	With the Start COM button the communication to the Master can be started.
Stop COM	With the Stop COM button the communication to the Master can be stopped.
Reset	With the Reset button the device can be reset.

Table 26: Start COM, Stop COM, Reset

8 Troubleshooting

<u>General</u>

> Check, if the requirements for cifX card operation are served:

Further information to this you find in section *Requirements for Operation* on page 18.

LINK-LED

Check using the LINK LED status, if a connection to the Ethernet is established.

Further information to this you find in chapter *LED Real Time Ethernet Systems* on page 58.

<u>Cable</u>

> Check that the pin occupation of the used cable is correct.

Configuration

Check the configuration in the Master and the Slave device. The configuration has to match.

Diagnostic using the netX Configuration and Diagnostic Utility (Slave)

With the menu **netX Configuration and Diagnostic Utility > Diagnostics** the diagnosis information of the Slave device is shown. The shown diagnostic information depends on the used protocol.

Diagnostic using the System Configurator SYCON.net (Master)

With the menu **Online > Diagnosis** the diagnosis information of the Master device is shown. The shown diagnostic information depends on the used protocol.



Note: More information about the device diagnosis and its functions you find in the operating manual of the corresponding Real Time Ethernet system. Therefore refer to section *Documentations cifX Cards* on page 10.

9 Device Drawings and Connections

9.1 Device Drawing CIFX 50-RE



Note:

Device supports Auto Crossover Function

Note:

With loaded EtherNet/IP-Adapter, Scanner or EtherCAT Master firmware only channel 0 can be used, channel 1 is deactivated.

The meaning of the yellow and green LED at the RJ45 socket depends from the loaded firmware. See section *LED Real Time Ethernet Systems* beginning from page 58.

9.2 Device Drawing CIFX 50E-RE



Note:

Device supports Auto Crossover Function

Note:

With loaded EtherNet/IP-Adapter, Scanner or EtherCAT Master firmware only channel 0 can be used, channel 1 is deactivated.

Figure 18: Device Drawing CIFX 50E-RE

The meaning of the yellow and green LED at the RJ45 socket depends from the loaded firmware. See section *LED Real Time Ethernet Systems* beginning from page 58.

Figure 17: Device Drawing CIFX 50-RE

9.3 Device Drawing CIFX 80-RE



Note: Device supports Auto Crossover Function

Note: With loaded EtherNet/IP-Adapter, Scanner or EtherCAT Master firmware only channel 0 can be used, channel 1 is deactivated.

Figure 19: Device Drawing CIFX 80-RE

The meaning of the yellow and green LED at the RJ45 socket depends from the loaded protocol. See section *LED Real Time Ethernet Systems* beginning from page 58.

9.4 Device Drawing CIFX 90-RE



Figure 20: Device Drawing CIFX 90-RE

9.5 Device Drawing CIFX 104C-RE



Figure 21: Device Drawing CIFX 104C-RE

The meaning of the yellow and green LED at the RJ45 socket depends from the loaded firmware. See section *LED Real Time Ethernet Systems* beginning from page 58.

9.6 Device Drawing CIFX 104C-RE-R



Figure 22: Device Drawing CIFX 104C-RE-R

The meaning of the yellow and green LED at the RJ45 socket depends from the loaded firmware. See section *LED Real Time Ethernet Systems* beginning from page 58.

Note:

Device supports Auto Crossover Function

Note:

With loaded EtherNet/IP-Adapter, Scanner or EtherCAT Master firmware only channel 0 can be used, channel 1 is deactivated.

9.7 Device Drawing CIFX 104C-RE\F



Figure 23: Device Drawing CIFX 104C-RE\F

9.8 Device Drawing CIFX 104C-RE-R\F



Figure 24: Device Drawing CIFX 104C-RE-R\F

9.9 Device Drawing Connection Interface AIFX-RE

Only for CIFX 104C-RE\F, CIFX 104C-RE-R\F and CIFX 90-RE.



Note:

Device supports Auto Crossover Function

Note

With loaded EtherNet/IP-Adapter, Scanner or EtherCAT Master firmware only channel 0 can be used, channel 1 is deactivated.

Figure 25: Device Drawing Connection Interface AIFX-RE

The meaning of the yellow and green LED at the RJ45 socket depends from the loaded firmware. See section *LED Real Time Ethernet Systems* beginning from page 58.

9.10 Device Drawing Diagnosis Interface AIFX-DIAG

Only for CIFX 104C-RE\F and CIFX 104C-RE-R\F.



Figure 26: Device Drawing Diagnosis Interface AIFX-DIAG

9.11 Ethernet Interface

For the Ethernet interface use RJ45 plugs and twisted pair cable of category 5 (CAT5) or higher, which consists of 4 twisted cores and has a maximum transmission rate of 100 MBit/s (CAT5).

9.11.1 Ethernet pinning at the RJ45 Socket



Note: The device supports the Auto Crossover function. Due to this fact RX and TX can be switched. The following figure shows the RJ45 standard pinning.



Figure 27: Ethernet pinning at the RJ45 Socket

Pin	Signal	Meaning	
1	TX+	Transmit Data +	
2	TX–	Transmit Data –	
3	RX+	Receive Data +	
4	Term 1	Connected to each other and	
5	Term 1	terminated to PE through RC circuit*	
6	RX–	Receive Data –	
7	Term 2	Connected to each other and	
8	Term 2	terminated to PE through RC circuit*	
		* Bob Smith Termination	

Table 27: Ethernet pinning at the RJ45 Socket

9.11.2 Ethernet Connection Data

Medium	2 x 2 Twisted-Pair cupric cable, CAT5 (100 MBit/s)	
Length of cable	max. 100 m	
Transmission rate	10 MBit/s / 100 MBit/s	

Table 28: Ethernet Connection Data

9.11.3 Use of Hubs and Switches

For the corresponding communication systems the use of hubs and switches is forbidden or applicable. The following table shows the use of hubs and switches by communication system:

Communication System	Hub	Switch		
EtherCAT	forbidden	applicable only between Master and 1. participant		
PROFINET IO	forbidden	applicable only, if the switch supports 'priority tagging' (100 MBit/s, Full duplex)		
EtherNet/IP	allowed	applicable (10 MBit/s / 100 MBit/s, Full or Half Duplex, Auto-Negotiation)		
SERCOS III	forbidden	forbidden		

Table 29: Use of Hubs and Switches

9.12 Mini-B USB Connector (5 Pin)

Only for CIFX 80-RE, CIFX 104C-RE, CIFX 104C-RE-R. For CIFX 104C-RE\F, CIFX 104C-RE-R\F when using the AIFX-DIAG.



Figure 28: Mini-B USB Connector (5 Pin), S302

Pin	Name	Description	
1	USB_EXT	USB Bus Power (+5 V, supplied externally)	
2	D-	Data -	
3	D+	Data +	
4	ID	Not connected	
5	GND	Ground	

Table 30: Pin out, S302

9.13 Rotary Switch for Slot Number

Only for CIFX 104C devices

The *Rotary Switch for Slot Number* is used for setting the physical slot number. Max. 4 modules can be plugged on each other. Each slot setting can be used only one time. The module next to the host controller gets the CLK 0, the following modules get the next higher CLK number.

Switch Position	Module No. Slot	CLK	ID Select	INT
0, 4, 8	1	CLK 0	IDSEL 0	INTA
1, 5, 9	2	CLK 1	IDSEL 1	INTB
2, 6	3	CLK 2	IDSEL 2	INTC
3, 7	4	CLK 3	IDSEL 3	INTD

Table 31: Rotary Switch for Slot Number, S1

9.14 Cable Connector

9.14.1 Pinning for Cable Connector Ethernet

Only for CIFX 104C-RE\F (X304), CIFX 104C-RE-R\F (X4) and CIFX 90-RE (X4).

Pin	Signal
1	GND
2	+3V3 Analog
3	STA0_green
4	STA0_red
5	XM0_TX
6	STA1_green
7	CH0_LINKn
8	CH0_ACTIVITY
9	AIFINIT
10	STA1_red
11	CH0_TXP
12	CH0_TXN
13	CH0_RXP
14	CH0_RXN
15	CH1_TXP
16	CH1_TXN
17	CH1_RXP
18	CH1_RXN
19	CH1_LINKn
20	CH1_ACTIVITY

Table 32: Pinning for Cable Connector Ethernet X4 or X304 – Cable 20 pin Ethernet + Status LED

9.14.2 Pinning for Cable Connector DIAG

Only for CIFX 104C-RE\F (X303), CIFX 104C-RE-R\F (X3).

Pin	Signal
1	GND
2	+3V3
3	STA2
4	STA3
5	USB_POS
6	USB_NEG
7	RDYn
8	RUNn
9	STA0_green
10	STA0_red
11	STA1_green
12	STA1_red

Table 33: Pinning for Cable connector DIAG X3 or X303 - Cable 12 pin USB + Status LED

9.14.3 Pinning for SYNC Connector, X51

Only for CIFX 80-RE, CIFX 90-RE, CIFX 104C-RE, CIFX 104C-RE-R, CIFX 104C-RE\F, CIFX 104C-RE-R\F.

Pin	Signal	
1	GND	
2	IO_0 XMAC3	
3	IO_1 XMAC3	

Table 34: Pinning for SYNC Connector, X51

10 LED

10.1 LED Real Time Ethernet Systems

10.1.1 LED Names for each Real Time Ethernet System



Note: Depending from the loaded cifX firmware the cifX LED are configured to the corresponding real-time Ethernet system.

cifX-LED		EtherCAT Master	EtherCAT Slave	Ether Net/IP	Powerlink	Open Modbus/TCP	PROFINET IO	SERCOS III
SYS (yellow / green)		SYS	SYS	SYS	SYS	SYS	SYS	SYS
COM 0 (red/ green)		RUN	RUN	MS	BS	RUN	SF	STA
COM 1 (red/ green)		ERR	ERR	NS	BE	ERR	BF	ERR
RJ45 Ch0	green	LINK	L/A IN	LINK	L/A	LINK	LINK	L/A
	yellow	ACT	-	ACT	-	ACT	RX/TX	-
RJ45 Ch1	green	-	L/A OUT	LINK	L/A	LINK	LINK	L/A
	yellow	-	-	ACT	-	ACT	RX/TX	-

Table 35: LED Names for each Real Time Ethernet System

LED	Name	Meaning
System Status	SYS	System
	RUN	Run
	ERR	Error
	STA	Status
	SF	System Failure
Communication Status	BF	Bus Failure
	MS	Module Status
	NS	Network Status
	BS	Bus Status
	BE	Bus Error
	LINK, L	Link
	ACT, A	Activity
RJ45	L/A	Link/Activity
	L/A IN	Link/Activity Input
	L/A OUT	Link/Activity Output

Table 36: Meaning LED Names

10.1.2	LED EtherCAT Master	

LED	Color	State	Meaning
SYS	green	On	Operating System running
	yellow	Flashing cyclic with 1Hz	Device indicates boot error
	yellow	static	Bootloader is waiting for booting procedure
	-	Off	Power supply for the device is missing or hardware defect
RUN	-	Off	INIT: The device is in state INIT
	green	Blinking	PRE-OPERATIONAL: The device is in state PRE- OPERATIONAL
	green	Flickering	BOOT: Device is in Boot mode
	green	Single Flash	SAFE-OPERATIONAL: The device is in state SAFE- OPERATIONAL
	green	On	OPERATIONAL: The device is in state OPERATIONAL
ERR	-	Off	Master has no errors
	red	On	Master has detected a communication error. The error is indicated in the DPM
LINK / RJ45 Ch0	green	On	A link is established
& Ch1	-	Off	No link established
ACT / RJ45 Ch0 & Ch1	yellow	Flashing	The device sends/receives Ethernet frames

Table 37: EtherCAT Master

RUN and ERR LED Indicator States EtherCAT Master:

Indicator state	Definition	
On	The indicator is constantly on.	
Off	The indicator is constantly off.	
Blinking	The indicator turns on and off phase with a frequency of 2,5 Hz: on for 200 ms followed by off for 200 ms.	
Flickering	The indicator turns on and off phase with a frequency of approximately 10 Hz: on for approximately 50 ms followed by o for 50 ms.	
Single Flash	The indicator shows one short flash (200 ms) followed by a long off phase (1,000 ms).	
Double Flash	The indicator shows a sequence of two short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).	

Table 38: Indicator States EtherCAT Master

10.1.3 LED EtherCAT Slave

LED	Color	State	Meaning
SYS	green	On	Operating System running
	yellow	Flashing cyclic with 1Hz	Device indicates boot error
	yellow	static	Bootloader is waiting for booting procedure
	-	Off	Power supply for the device is missing or hardware defect
RUN	-	Off	INIT: The device is in state INIT
	green	Blinking	PRE-OPERATIONAL: The device is in state PRE-OPERATIONAL
	green	Single Flash	SAFE-OPERATIONAL: The device is in state SAFE- OPERATIONAL
	green	On	OPERATIONAL: The device is in state OPERATIONAL
ERR	-	Off	No error: The EtherCAT communication of the device is in working condition
	red	Blinking	Invalid Configuration: General Configuration Error (Example: State change commanded by master is impossible due to register or object settings.)
	red	Single Flash	Unsolicited State Change: Slave device application has changed the EtherCAT state autonomously: Parameter "Change" in the AL status register is set to 0x01:change/error (Example: Synchronization Error, device enters Safe-Operational automatically.)
	red	Double Flash	Application Watchdog Timeout: An application watchdog timeout has occurred. (Example: Sync Manager Watchdog timeout)
	red	On	PDI Watchdog Timeout: A PDI Watchdog timeout has occurred (Example: Application controller is not responding any more)
L/A IN /	green	On	A link is established
RJ45 Ch0 & Ch1	green	Flashing	The device sends/receives Ethernet frames
	-	Off	No link established
L/A OUT / RJ45 Ch0 & Ch1	yellow	-	-

Table 39: EtherCAT Slave

RUN and ERR LED Indicator States EtherCAT Slave:

Indicator state Definition		
On	The indicator is constantly on.	
Off	The indicator is constantly off.	
Blinking The indicator turns on and off phase with a frequency of 2,5 Hz: on for 200 ms followed by off for 200 ms.		
Single Flash The indicator shows one short flash (200 ms) followed by long off phase (1,000 ms).		
Double Flash	The indicator shows a sequence of two short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).	

Table 40: Indicator States EtherCAT Slave

Hilscher Gesellschaft für Systemautomation mbH – Rheinstr. 15 – D 65795 Hattersheim Edition 9 – UM:CIFX-RE#EN – 2008/06

LED	Color	State	Meaning
SYS	green	On	Operating System running.
	yellow	Flashing cyclic with 1Hz	Device indicates boot error.
	yellow	static	Bootloader is waiting for booting procedure.
	-	Off	Power supply for the device is missing or hardware defect.
MS	green	On	Device operational: If the device is operating correctly, the module status indicator shall be steady green.
	green	Flashing	Standby: If the device has not been configured, the module status indicator shall be flashing green.
	red	On	Major fault: If the device has detected a non-recoverable major fault, the module status indicator shall be steady red.
	red	Flashing	Minor fault*: If the device has detected a recoverable minor fault, the module status indicator shall be flashing red. NOTE: An incorrect or inconsistent configuration would be considered a minor fault. (*for future use)
	red / green	Flashing	Self-test: While the device is performing its power up testing, the module status indicator shall be flashing green / red.
	-	Off	No power: If no power is supplied to the device, the module status indicator shall be steady off.
NS	green	On	Connected: If the device has at least one established connection (even to the Message Router), the network status indicator shall be steady green.
	green	Flashing	No connections: If the device has no established connections, but has obtained an IP address, the network status indicator shall be flashing green.
	red	On	Duplicate IP*: If the device has detected that its IP address is already in use, the network status indicator shall be steady red. (*For future use)
	red	Flashing	Connection timeout: If one or more of the connections in which this device is the target has timed out, the network status indicator shall be flashing red. This shall be left only if all timed out connections are reestablished or if the device is reset.
	red / green	Flashing	Self-test: While the device is performing its power up testing, the network status indicator shall be flashing green / red.
	-	Off	Not powered, no IP address: If the device does not have an IP address (or is powered off), the network status indicator shall be steady off.
LINK /	green	On	A connection to the Ethernet exists
RJ45 Ch0 & Ch1	-	Off	The device has no connection to the Ethernet
ACT / RJ45 Ch0 & Ch1	yellow	Flashing	The device sends/receives Ethernet frames

10.1.4 LED EtherNet/IP Scanner (Master)

Table 41: EtherNet/IP Scanner (Master)

LED	Color	State	Meaning
SYS	green	On	Operating System running.
	yellow	Flashing cyclic with 1Hz	Device indicates boot error.
	yellow	static	Bootloader is waiting for booting procedure.
	-	Off	Power supply for the device is missing or hardware defect.
MS	green	On	Device operational: If the device is operating correctly, the module status indicator shall be steady green.
	green	Flashing	Standby: If the device has not been configured, the module status indicator shall be flashing green.
	red	On	Major fault: If the device has detected a non-recoverable major fault, the module status indicator shall be steady red.
	red	Flashing	Minor fault*: If the device has detected a recoverable minor fault, the module status indicator shall be flashing red. NOTE: An incorrect or inconsistent configuration would be considered a minor fault. (* For future use)
	red / green	Flashing	Self-test: While the device is performing its power up testing, the module status indicator shall be flashing green / red.
	-	Off	No power: If no power is supplied to the device, the module status indicator shall be steady off.
NS	green	On	Connected: If the device has at least one established connection (even to the Message Router), the network status indicator shall be steady green.
	green	Flashing	No connections: If the device has no established connections, but has obtained an IP address, the network status indicator shall be flashing green.
	red	On	Duplicate IP*: If the device has detected that its IP address is already in use, the network status indicator shall be steady red. (* For future use)
	red	Flashing	Connection timeout: If one or more of the connections in which this device is the target has timed out, the network status indicator shall be flashing red. This shall be left only if all timed out connections are reestablished or if the device is reset.
	red / green	Flashing	Self-test: While the device is performing its power up testing, the network status indicator shall be flashing green / red.
	-	Off	Not powered, no IP address: If the device does not have an IP address (or is powered off), the network status indicator shall be steady off.
	green	On	A connection to the Ethernet exists
RJ45 Ch0 & Ch1	-	Off	The device has no connection to the Ethernet
ACT / RJ45 Ch0 & Ch1	yellow	Flashing	The device sends/receives Ethernet frames

10.1.5 LED EtherNet/IP Adapter (Slave)

Table 42: EtherNet/IP Adapter (Slave)

10.1.6 LED Open Modbus/TCP

LED	Color	State	Meaning
SYS	green	On	Operating System running.
	yellow	Flashing cyclic with 1Hz	Device indicates boot error.
	yellow	static	Bootloader is waiting for booting procedure.
	-	Off	Power supply for the device is missing or hardware defect.
RUN	-	Off	Not Ready OMB task is not ready
	green	Flashing cyclic with 1Hz	Ready, not configured yet OMB task is ready and not configured yet
	green	Flashing cyclic with 5Hz	Waiting for Communication: OMB task is configured
	green	On	Connected: OMB task has communication – at least one TCP connection is established
ERR	-	Off	No communication error
	red	Flashing cyclic with 2Hz (On/Off Ratio = 25 %)	System error
	red	On	Communication error active
LINK /	green	On	A connection to the Ethernet exists
RJ45 Ch0 & Ch1	-	Off	The device has no connection to the Ethernet
ACT / RJ45 Ch0 & Ch1	yellow	Flashing	The device sends/receives Ethernet frames

Table 43: LED Open Modbus/TCP

LED	Color	State	Meaning
SYS	green	On	Operating System running.
	yellow	Flashing cyclic with 1Hz	Device indicates boot error.
	yellow	static	Bootloader is waiting for booting procedure.
	-	Off	Power supply for the device is missing or hardware defect.
BS	-	Off	Slave initializing
	green	Flickering	Slave is in Basic Ethernet state
		Single Flash	Slave is in Pre-Operational 1
		Double Flash	Slave is in Pre-Operational 2
		Triple Flash	Slave is in ReadyToOperate
		On	Slave is Operational
		Blinking	Slave is Stopped
BE	-	Off	Slave has no error
	red	On	Slave has detected an error
	green	On	Link: A connection to the Ethernet exists
RJ45 Ch0 & Ch1	green	Flashing	Activity: The device sends/receives Ethernet frames
	-	Off	The device has no connection to the Ethernet
RJ45 Ch0 & Ch1	yellow	-	-

10.1.7 LED Powerlink Controlled Node / Slave

Table 44: LED Powerlink Controlled Node / Slave

RUN / ERR LED Indicator Powerlink Controlled Node / Slave:

Indicator state	Definition	
On	The indicator is constantly on.	
Off	The indicator is constantly off.	
Flickering	The indicator turns on and off phase with a frequency of approximately 10 Hz: on for approximately 50 ms followed by off for 50 ms. Red and green LED shall be on alternately.	
Blinking	The indicator turns on and off phase with a frequency of approximately 2,5 Hz: on for approximately 200 ms followed by off for 200 ms. Red and green LED shall be on alternately.	
Single Flash	The indicator shows one short flash (approximately 200 ms) followed by a long off phase (approximately 1,000 ms).	
Double Flash	The indicator shows a sequence of two short flashes (each approximately 200 ms), separated by a short off phase (approximately 200 ms). The sequence is finished by a long off phase (approximately 1,000 ms).	
Triple Flash	The indicator shows a sequence of three short flashes (each approximately 200 ms), separated by a short off phase (approximately 200 ms). The sequence is finished by a long off phase (approximately 1,000 ms).	

Table 45: Indicator States Powerlink Controlled Node / Slave

LED	Color	State	Meaning
SYS	green	On	Operating System running
	yellow	Flashing cyclic at 1Hz	Device indicates boot error
	yellow	Static	Bootloader is waiting for booting procedure
	-	Off	Power supply for the device is missing or hardware defect
SF	red	On	(together with BF "red ON")
			No valid Master license
	red	Flashing cyclic at 2 Hz	System error: Invalid configuration
	-	Off	No error
BF	red	On	No Connection: No Link.
			or (together with SF "red ON")
			No valid Master license
	red	Flashing cyclic at 2 Hz	Configuration fault: not all configured IO-Devices are connected.
	-	Off	No error
LINK /	green	On	A connection to the Ethernet exists
RJ45 Ch0 & Ch1	-	Off	The device has no connection to the Ethernet
RX/TX / RJ45 Ch0 & Ch1	yellow	Flashing	The device sends/receives Ethernet frames

10.1.8 LED PROFINET IO-RT Controller

Table 46: PROFINET IO-RT Controller

10.1.9 LED PROFINET IO-RT-Device

LED	Color	State	Meaning
SYS	green	On	Operating System running
	yellow	Flashing cyclic at 1Hz	Device indicates boot error
	yellow	static	Bootloader is waiting for booting procedure
	-	Off	Power supply for the device is missing or hardware defect
SF	red	On	Watchdog timeout; channel, generic or extended diagnosis present; system error
	red	Flashing cyclic at 2 Hz (for 3 sec.)	DCP signal service is initiated via the bus
	-	Off	No error
BF	red	On	No configuration; or low speed physical link; or no physical link
	red	Flashing cyclic at 2 Hz	No data exchange
	-	Off	No error
	green	On	A connection to the Ethernet exists
RJ45 Ch0 & Ch1	-	Off	The device has no connection to the Ethernet
RX/TX / RJ45 Ch0 & Ch1	yellow	Flashing	The device sends/receives Ethernet frames

Table 47: PROFINET IO-RT-Device

LED	Color	State	Meaning
SYS	green	On	Operating System running.
	yellow	Flashing cyclic with 1Hz	Device indicates boot error.
	yellow	static	Bootloader is waiting for booting procedure.
	-	Off	Power supply for the device is missing or hardware defect.
STA	green	Blinking	CP0: Communication phase 0
	green	Single Flash	CP1: Communication phase 1
	green	Double Flash	CP2: Communication phase 2
	green	Triple Flash	CP3: Communication phase 3
	green	On	CP4: Communication phase 4
	-	Off	NRT: Non Real-time Mode
ERR	red	On	Error
	-	Off	No error
L/A /	green	On	Link: A connection to the Ethernet exists
RJ45 Ch0 & Ch1	green	Flashing	Activity: The device sends/receives Ethernet frames
	-	Off	The device has no connection to the Ethernet
RJ45 Ch0 & Ch1	yellow	-	-

10.1.10 LED SERCOS III Slave

Table 48: SERCOS III Slave

RUN and STA LED Indicator States SERCOS III Slave:

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Blinking	The indicator turns on and off phase with a frequency of 2,5 Hz: on for 200 ms followed by off for 200 ms.
Single Flash	The indicator shows one short flash (200 ms) followed by a long off phase (1,000 ms).
Double Flash	The indicator shows a sequence of two short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).
Triple Flash	The indicator shows a sequence of three short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).

Table 49: Indicator States SERCOS III Slave

11 Technical Data

11.1 Technical Data cifX Real-Time Ethernet Cards



 $\ensuremath{\textbf{Note:}}$ All technical data are temporarily and can be altered without notice.

11.1.1 CIFX 50-RE

Item	CIFX 50-RE
System Interface	PCI, 32-Bit Dual-Port Memory
Dual-Port Memory Size	64 KBytes
Function	Real-Time-Ethernet
Communication	Determined by the loaded firmware
Protocols	EtherCAT-Master, EtherCAT-Slave, EtherNet/IP-Scanner (Master), EtherNet/IP-Adapter (Slave), Open Modbus/TCP, Powerlink Controlled Node / Slave, PROFINET IO-Controller, PROFINET IO-Device, SERCOS III-Slave
Ethernet Frame Types	Ethernet II
Processor	netX 500
LED	SYS, COM 0, COM 1, 2x Link, 2x Activity
GUI cifX	netX Configuration and Diagnostic Utility
Transmission Rate	10/100 MBit/s, Auto-Negotiation, Cross-Over, Halfduplex/Fullduplex (100 MBit/s) Depending on used firmware
Ethernet Interface	RJ45 Socket, 10 Base-T, 100 Base-TX, potential free
Power Supply	+3,3 V ±5 % / 600 mA
Dimensions (L x W x D)	120,0 x 73,2 x 18,5 mm
Operating Temperature	0 °C 55 °C

Table 50: Technical Data CIFX 50-RE

11.1.2 CIFX 50E-RE

Item	CIFX 50E-RE
System Interface	PCI-Express, Single-Lane Port, 32-Bit Dual-Port Memory
Dual-Port Memory Size	64 KBytes
Function	Real-Time-Ethernet
Communication	Determined by the loaded firmware
Protocols	EtherCAT-Master, EtherCAT-Slave, EtherNet/IP-Scanner (Master), EtherNet/IP-Adapter (Slave), Open Modbus/TCP, Powerlink Controlled Node / Slave, PROFINET IO-Controller, PROFINET IO-Device, SERCOS III-Slave
Ethernet Frame Types	Ethernet II
Processor	netX 500
LED	SYS, COM 0, COM 1, 2x Link, 2x Activity
GUI cifX	netX Configuration and Diagnostic Utility
Transmission Rate	10/100 MBit/s, Auto-Negotiation, Cross-Over, Halfduplex/Fullduplex (100 MBit/s) Depending on used firmware
Ethernet Interface	RJ45 Socket, 10 Base-T, 100 Base-TX, potential free
Power Supply	+3,3 V ±5 % / 600 mA
Dimensions (L x W x D)	120,0 x 77,6 x 18,5 mm
Operating Temperature	0 °C 55 °C

Table 51: Technical Data CIFX 50E-RE

11.1.3 CIFX 80-RE

ltem	CIFX 80-RE
System Interface	Compact PCI (3,3 V)
Dual-Port Memory Size	64 KBytes
Function	Real-Time-Ethernet
Communication	Determined by the loaded firmware
Protocols	EtherCAT-Master, EtherCAT-Slave, EtherNet/IP-Scanner (Master), EtherNet/IP-Adapter (Slave), Open Modbus/TCP, Powerlink Controlled Node / Slave, PROFINET IO-Controller, PROFINET IO-Device, SERCOS III-Slave
Ethernet Frame Types	Ethernet II
Processor	netX 500
LED	SYS, COM 0, COM 1, 2x Link, 2x Activity
GUI cifX	netX Configuration and Diagnostic Utility
Transmission Rate	10/100 MBit/s, Auto-Negotiation, Cross-Over, Halfduplex/Fullduplex (100 MBit/s)
Ethernet Interface	RJ45 Socket, 10 Base-T, 100 Base-TX, potential free
Power Supply	+3,3 V ±5 % / 600 mA
Dimensions (L x W x D)	100,0 x 160,0 x 9,4 mm
Operating Temperature	-20 °C 55 °C

Table 52: Technical Data CIFX 80-RE

11.1.4 CIFX 90-RE

Item	CIFX 90-RE
System Interface	Mini-PCI-Socket (3,3 V), Type III System Connector
Dual-Port Memory Size	64 KBytes
Function	Real-Time-Ethernet
Communication	Determined by the loaded firmware
Protocols	EtherCAT-Master, EtherCAT-Slave, EtherNet/IP-Scanner (Master), EtherNet/IP-Adapter (Slave), Open Modbus/TCP, Powerlink Controlled Node / Slave, PROFINET IO-Controller, PROFINET IO-Device, SERCOS III-Slave
Ethernet Frame Types	Ethernet II
Processor	netX 500
LED	SYS
GUI cifX	netX Configuration and Diagnostic Utility
Transmission Rate	10/100 MBit/s, Auto-Negotiation, Cross-Over, Halfduplex/Fullduplex (100 MBit/s) Depending on used firmware
Interface AIFX-RE	Cable Connector Ethernet for connecting connection interface AIFX-RE
Power Supply	+3,3 V ±5 % / 600 mA
Dimensions (L x W x D)	60,0 x 44,6 x 9,4 mm
Operating Temperature	-20 °C 70 °C

Table 53: Technical Data CIFX 90-RE

11.1.5 CIFX 104C-RE, CIFX 104C-RE-R, CIFX 104C-RE\F, CIFX 104C-RE-R\F

Item	CIFX 104C-RE, CIFX 104C-RE-R, CIFX 104C-RE\F, CIFX 104C-RE-R\F
System Interface	PCI Slot for PC/104 cards (3,3 V)
Dual-Port Memory Size	64 KBytes
Function	Real-Time-Ethernet
Communication	Determined by the loaded firmware
Protocols	EtherCAT-Master, EtherCAT-Slave, EtherNet/IP-Scanner (Master), EtherNet/IP-Adapter (Slave), Open Modbus/TCP, Powerlink Controlled Node / Slave, PROFINET IO-Controller, PROFINET IO-Device, SERCOS III-Slave
Ethernet Frame Types	Ethernet II
Processor	netX 500
LED	SYS, COM 0, COM 1, 2x Link, 2x Activity
GUI cifX	netX Configuration and Diagnostic Utility
Transmission Rate	10/100 MBit/s, Auto-Negotiation, Cross-Over, Halfduplex/Fullduplex (100 MBit/s) Depending on used firmware
Ethernet Interface	For CIFX 104C-RE, CIFX 104C-RE-R : RJ45 Socket, 10 Base-T, 100 Base-TX, potential free
Interface AIFX-RE	For CIFX 104C-RE\F, CIFX 104C-RE-R\F : Cable Connector Ethernet for connecting AIFX-RE
Diagnostic Interface	For CIFX 104C-RE\F, CIFX 104C-RE-R\F : Cable Connector DIAG
Power Supply	+3,3 V ±5 % / 600 mA
Dimensions (L x W x D)	96,0 x 90,2 x 26,5 mm
Operating Temperature	-20 °C 55 °C

Table 54: Technical Data CIFX 104C-RE, CIFX 104C-RE-R, CIFX 104C-RE\F, CIFX 104C-RE-R\F
11.1.6 AIFX-RE

ltem	AIFX-RE	
Function	Connection Interface Ethernet	
Interface cifX-RE Cards	For CIFX 90-RE, CIFX 104C-RE\F, CIFX 104C-RE-R\F : Cable Connector Ethernet for connecting AIFX-RE	
Ethernet Interface	RJ45 Socket, 10 Base-T, 100 Base-TX, potential free	
Transmission Rate	10/100 MBit/s, Auto-Negotiation, Cross-Over, Halfduplex/Fullduplex (100 MBit/s) Depending on used firmware	
Dimensions (L x W x D)	42,5 x 30,6 x 18,5 mm	
Operating Temperature	-20 °C 70 °C	

Table 55: Technical Data AIFX-RE

11.1.7 AIFX-DIAG

ltem	AIFX-DIAG
Function	Diagnostic Interface
Diagnostic Interface	For CIFX 104C-RE\F, CIFX 104C-RE-R\F : Cable Connector DIAG
Dimensions (L x W x D)	53,5 x 23,3 x 14,7 mm
Operating Temperature	-20 °C 70 °C
LED	SYS, COM 0, COM 1, COM 2, COM 3, ON

Table 56: Technical Data AIFX-DIAG

11.2 Protocols

11.2.1 EtherCAT Master

Parameter	Description
Maximum number of cyclic input data	5760 bytes
Maximum number of cyclic output data	5760 bytes
Minimum bus cycle time	500 microseconds
Acyclic communication	CoE (CANopen over EtherCAT)
	CoE-Upload, CoE-Download
	max. 1500 bytes
Functions	Get OD List
	Emergency
	Slave diagnostics
Topology	Line
Baud rate	100 MBit/s
Data transport layer	Ethernet II, IEEE 802.3
Configuration File	Max. 1 MByte

Table 57: EtherCAT Master

11.2.2 EtherCAT Slave

Parameter	Description	
Maximum number of cyclic input data	400 bytes (netX 100/netX 500)	
Acyclic communication	SDO	
	SDO Master-Slave	
	SDO Slave-Slave (depending on Master capability)	
Туре	Complex Slave	
Functions	Emergency	
FMMUs	3 (netX 100/netX 500)	
SYNC Manager	4 (netX 100/500)	
Baud rate	100 MBit/s	
Data transport layer	Ethernet II, IEEE 802.3	

Table 58: EtherCAT Slave

11.2.3 EtherNet/IP Scanner (Master)

Parameter	Description	
Maximum number of total cyclic input data	5760 bytes	
Maximum number of total cyclic output data	5760 bytes	
Maximum number of supported connections	64 connections for implicit and explicit	
Maximum number of cyclic input data	504 bytes/slave/telegram	
Maximum number of cyclic output data	504 bytes/slave/telegram	
IO Connection type	Cyclic, minimum 2 ms *	
Maximum number of unscheduled data	1400 bytes per telegram	
UCMM, Class 3	supported	
Explicit Messages, Client and Server	Get_Attribute_Single/All	
Services	Set_Attribute_Single/All	
Predefined standard objects	Identity Object	
	Message Route Object	
	Assembly Object	
	Connection Manager	
	Ethernet Link Object	
	TCP/IP Object	
Maximal number of user specific objects	20	
DHCP	supported	
BOOTP	supported	
Baud rates	10 and 100 MBit/s	
Data transport layer	Ethernet II, IEEE 802.3	
* depending on used number of connections and used number of input and output data		

Table 59: EtherNet/IP Scanner (Master)

11.2.4 EtherNet/IP Adapter (Slave)

Parameter	Description
Maximum number of input data	504 bytes
Maximum number of output data	504 bytes
IO Connection	1 explicit owner, up to 2 listen only
IO Connection type	Cyclic, minimum 2 ms
Explicit Messages	Get_Attribute, Set_Attribute
UCMM	supported
Max. number of user specific objects	20
Max. number of connections	8, explicit and implicit connections
Predefined standard objects	Identity Object
	Message Route Object
	Assembly Object
	Connection Manager
	Ethernet Link Object
	TCP/IP Object
DHCP	supported
BOOTP	supported
Baud rates	10 and 100 MBit/s
Data transport layer	Ethernet II, IEEE 802.3

Table 60: EtherNet/IP Adapter (Slave)

11.2.5 Open Modbus/TCP

Parameter	Description	
Maximum number of input data	5760 bytes	
Maximum number of output data	5760 bytes	
Acyclic communication	Read/Write Register, Max. 125 Registers per Read Telegram (FC 3, 4, 23), Max. 121 Registers per Write Telegram (FC 23), Max. 123 Registers per Write Telegram (FC 6)	
	Read/Write Coil, Max. 2000 Coils per Read Telegram (FC 1, 2), Max. 1968 Coils per Write Telegram (FC 15)	
Modbus Function Codes	1, 2, 3, 4, 5, 6, 7, 15, 16, 23	
Mode	Message Mode: Client, Server (I/O data area is not used in this mode)	
	I/O Mode: Server	
Baud rates	10 and 100 MBit/s	
Data transport layer	Ethernet II, IEEE 802.3	

Table 61: Open Modbus/TCP

11.2.6 Powerlink Controlled Node / Slave

Parameter	Description
Maximum number of cyclic input data	1490 bytes
Maximum number of cyclic output data	1490 bytes
Acyclic data transfer	SDO Upload/Download
Functions:	SDO over ASND and UDP
Baud rate	100 MBit/s, half-duplex
Data transport layer	Ethernet II, IEEE 802.3
Ethernet Powerlink version	V 2

Table 62: Powerlink Controlled Node / Slave

11.2.7 PROFINET IO-RT-Controller

Parameter	Description	
Maximum number of total cyclic input data	3072 bytes	
Maximum number of total cyclic output data	3072 bytes	
Maximum number of cyclic input data	1024 bytes per device (= IOCR data length)	
Maximum number of cyclic output data	1024 bytes per device (= IOCR data length)	
Maximum number of configured devices	128	
Acyclic communication	Read/Write Record	
	Limited to 1392 bytes per telegram	
	Limited to 4096 bytes per request	
Alarm processing	yes	
DCP	supported	
Context management by CL-RPC		
Minimum cycle time	1ms	
	Different IO-Devices can be configured with different cycle times	
Baud rate	100 MBit/s	
	Full-Duplex mode	
Data transport layer	Ethernet II, IEEE 802.3	
Configuration File	Max. 1 MByte	
Limitations	RT over UDP not supported	
	Multicast communication not supported	
	DHCP is not supported (neither for PROFINET IO- Controller nor for the IO-Devices)	
	Only one IOCR per IO-Device	
	Using cycle time of less than 4ms reduces the maximum amount of connected devices to 25	
	NameOfStation of IO-Controller CANNOT be set using the DCP SET NameOfStation service but only at start-up while configuring the IO-Controller	
	SNMP not supported	
	LLDP not supported	

Table 63: PROFINET IO-RT-Controller

11.2.8 **PROFINET IO-RT-Device**

Parameter	Description	
Maximum number of cyclic input data	1024 bytes	
Maximum number of cyclic output data	1024 bytes	
Maximum number of all submodules	80	
Maximum slot address	300	
Maximum subslot address	100	
Acyclic communication	Read/Write Record, max. 1024 bytes/telegram	
Alarm Types	Process Alarm, Diagnostic Alarm, Return of SubModule, Plug Alarm, Pull Alarm	
DCP	supported	
Used Protocols (subset)	UDP, IP, ARP, ICMP (Ping)	
Topology recognition	LLDP, SNMP V1, MIB2, physical device	
VLAN- and priority tagging	yes	
Context Management by CL-RPC		
Minimum cycle time	1ms	
	IO-Device can be configured with different cycle times	
Baud rate	100 MBit/s	
Data transport layer	Ethernet II, IEEE 802.3	

Table 64: PROFINET IO-RT-Device

11.2.9 SERCOS III Slave

Parameter	Description	
Maximum number of cyclic input data	200 bytes (including Device Control, Connection Control)	
Maximum number of cyclic output data	200 bytes (including Device Status, Connection Control)	
Maximum number of applicable device addresses	1	
Minimum cycle time	250µs	
Topology	Line and ring	
Acyclic communication (Service Channel)	Read/Write/Standard Commands	
NRT Channel supported	yes	
Communication phases	NRT, CP0, CP1, CP2, CP3, CP4	
Baud rate	100 MBit/s	
Data transport layer	Ethernet II, IEEE 802.3	
Supported SERCOS III version:	Communication Specification Version 1.1	
Supported SERCOS Communication Profiles	SCP_VarCFG, SCP_NRT, SCP_Sync	

Table 65: SERCOS III Slave



Note: The Firmware is based on the SERCOS III specification V1.1.

12 Configuration Parameters

12.1.1 EtherCAT Slave Parameters

Parameter	Meaning	Range of Value / Value	
Interface			
Bus Startup	Communication start application controlled or automatic	Application controlled, Automatic	
Watchdog Time [ms]	Watchdog time within which the device watchdog must be retriggered from the application program while the application program monitoring is activated. When the watchdog time value is equal to 0 the watchdog respectively the application program monitoring is deactivated.	[0, 20 65535] ms, default = 1000 ms, 0 = Off	
I/O Data Status	Status of the input or the output data.	None, (1 Byte, 4 Byte)	
	For each input and output date the following status information (in Byte) is memorized in the dual-port memory: Status 0 = None (default) Status 1 = 1 Byte (for future use) Status 2 = 4 Byte (for future use)		
Ident			
Vendor ID	Identification number of the manufacturer	0 (2 ³² - 1), Hilscher: 044 (hex)	
Product Code	Product code of the device	0 (2 ³² - 1), Default: CIFX RE ECS: 0x00000001 NXSTK 50-RE ECS: 0x00000008	
Revision Number	Revision number of the device	0 (2 ³² - 1), Default: CIFX RE ECS: 0x00020000 NXSTK 50-RE ECS: 0x00000000	
Serial Number	Serial number of the device	0 (2 ³² - 1)	
Data	Data		
Input Length	Length of the input data in Byte	0 400* Byte Default: 4 Byte	
Output Length	Length of the output data in Byte	0 … 400* Byte Default: 4 Byte	
* Sum: The lengt	* Sum: The length of input and of output is equal 400 Bytes,		

Table 66: EtherCAT Slave Parameters



Note: To configure the Master a XML file (device description file) is required. The settings in the used Master must comply with the settings in the Slave, to establish a communication. Important parameters are: Vendor ID, Product Code, Serial Number, Revision Number, Output and Input length.

12.1.2 EtherNet/IP Adapter Parameters

Parameter	Meaning	Range of Value / Value
Interface		
Bus Startup	Communication start application controlled or automatic	Application controlled, Automatic
Watchdog Time [ms]	Watchdog time within which the device watchdog must be retriggered from the application program while the application program monitoring is activated. When the watchdog time value is equal to 0 respectively the application program monitoring is deactivated.	[0, 20 65535] ms, default = 1000 ms, 0 = Off
I/O Data Status	Status of the input or the output data.	None, (1 Byte, 4 Byte)
	For each input and output date the following status information (in Byte) is memorized in the dual-port memory: Status 0 = None (default) Status 1 = 1 Byte (for future use) Status 2 = 4 Byte (for future use)	
Ident		
Vendor ID	Identification number of the manufacturer	283
Product Type	Communication Adapter	12
Product Code	Product code of the device	CIFX RE EIS: 101 (hex), 257 NXSTK 50-RE: 101 (hex), 257
Major Rev	Major Revision	1
Minor Rev	Minor Revision	1
Device name	Device name of the device station, e. g. EtherNet/IP Adapter (Slave)	Character string, 0 - 31 characters
Bus		
IP Address	IP address for the device	
Netmask	Network mask for the device	
Gateway	Gateway address for the device	
Flags	BootP: If set, the device obtains its IP Address, Netmask, Gateway Address from a BOOTP server. DHCP: If set, the device obtains its IP Address, Netmask, Gateway Address from a DHCP server	Default: DHCP
	100Mbit: Speed Selection, If set, the device will operate at 100 Mbit/s, else at 10 Mbit/s. This parameter will not be in effect, when auto-negotiation is active.	
	FullDuplex: Duplex Operation, If set, full-duplex operation will be used. The device will operate in half-duplex mode, if this parameter is set to zero. This parameter will not be in effect, when auto-negotiation is active.	
	Auto-neg.: Auto-Negotiation, If set, the device will auto-negotiate link parameters with the remote hub or switch.	
Data		
Input Length	Length of the input data in Byte	0 … 504 Byte Default: 2 Byte
Output Length	Length of the output data in Byte	0 … 504 Byte Default: 2 Byte

Table 67: EtherNet/IP Adapter Parameters



Note: To configure the Scanner/Master an EDS file (device description file) is required. The settings in the used Scanner/Master must comply with the settings in the Adapter/Slave, to establish a communication. Important parameters are: Input, Output length, Vendor ID, Product Type, Product Code, Major Rev, Minor Rev, IP Address and Netmask.

12.1.3 Open Modbus/TCP Parameters

Parameter	Meaning	Range of Value / Value
Interface		
Bus Startup	Communication start application controlled or automatic	Application controlled, Automatic
Watchdog Time [ms]	Watchdog time within which the device watchdog must be retriggered from the application program while the application program monitoring is activated. When the watchdog time value is equal to 0 the watchdog respectively the application program monitoring is deactivated.	[0, 20 65535] ms, default = 1000 ms, 0 = Off
Mode	Mode of data exchange.	0 <u>1</u>
	0: Message-Mode	
	1: IO-Mode	
Swap	Data-storage mode	<u>0</u> 1
	0: Data will not be swapped.	
	1: Data will be swapped.	
Bus		
Open Server	Server Connections	0 <u>4</u> 16
Sockets	Number of sockets to provide for server requests*	
	*A value of 0 means that the Open Modbus/TCP task exclusive works as Client, while a Value of 16 means that the Open Modbus/TCP task exclusive works as Server in Message-Mode.	
	The parameters Send Timeout, Connect Timeout and Close Timeout are for the Timeout between the Open Modbus/TCP Task and the TCP Task.	
Omb Open	Connection remain open time	1 <u>10</u> 60000
Time	Only for client jobs in message-mode. The connection to the destination-device stays open, until timeout is expired. Value is multiplied with 100 ms.	
	Note: This timeout starts, after receiving the answer to a command	
Answer Timeout	Telegram Timeout	1 <u>20</u> 60000
	Only for client jobs in message-mode. After expiration of this time, the job will be canceled and an error is send to the application. Value is multiplied with 100 ms.	
	Note: This timeout starts after command is send to the destination device via TCP	
Send Timeout	TCP Task SendTimeout Parameter	<u>0</u>
	Parameter for TCP task (in milliseconds) . Used OMB task internal. It specifies the timeout for trying to send messages via TCP/IP	2.000.000.000
	0 is the default value of 31000 milliseconds	
Connect	TCP Task Connect Timeout Parameter	<u>0</u>
Timeout	Parameter for TCP task (in milliseconds). Used OMB task internal. It specifies the timeout for trying to establish a connection with the TCP task.	2.000.000.000
	0 is the default value of 31000 milliseconds	
Close Timeout	TCP Task Close Timeout Parameter	<u>0</u>
	Parameter for TCP task (in milliseconds). Used OMB task internal. It specifies the timeout for trying to close a connection with the TCP task.	2.000.000.000
	0 is the default Value of 13000 milliseconds	
IP Address	IP address for the device.	Valid IP address

For more see next page

Parameter	Meaning	Range of Value / Value
Net Mask	Netmask for the subnet of the device.	Valid netmask
Gateway	IP address of the default gateway.	Valid IP address
Flags	BootP: If set, the device obtains its IP Address, Netmask, Gateway Address from a BOOTP server.	0 63
	DHCP: If set, the device obtains its IP Address, Netmask, Gateway Address from a DHCP server.	

Table 68: Open Modbus/TCP Parameters

Parameter	Meaning	Range of Value / Value
Interface		
Bus Startup	Communication start application controlled or automatic	Application controlled, Automatic
Watchdog Time [ms]	Watchdog time within which the device watchdog must be retriggered from the application program while the application program monitoring is activated. When the watchdog time value is equal to 0 the watchdog respectively the application program monitoring is deactivated.	[0, 20 65535] ms, default = 1000 ms, 0 = Off
I/O Data Status	Status of the input or the output data.	None, (1 Byte, 4 Byte)
	For each input and output date the following status information (in Byte) is memorized in the dual-port memory: Status 0 = None (default) Status 1 = 1 Byte (for future use) Status 2 = 4 Byte (for future use)	
Disable Host- Triggered Input Data	Bit 0 of the stack configuration flags controls the host- triggered input data exchange:	Default: Host- Triggered Update
Exchange	0 = Host-Triggered Update enabled	enabled
	1 = Host-Triggered Update disabled	
Disable Host- Triggered Output	Bit 1 of the stack configuration flags controls the host- triggered output data exchange:	Default: Host- Triggered Update
Data Exchange	0 = Host-Triggered Update enabled	enabled
	1 = Host-Triggered Update disabled	
Ident		
Vendor ID	Identification number of the manufacturer	44 hex
Serial Number	Serial number of the device	CIFX-RE: 0x00000000- 0xFFFFFFF
		Default: 0
Product Code	Product code of the device	CIFX RE PLS: 0x00000000- 0xFFFFFFF,
		Default:1
Revision Number	Revision number of the device as specified by the manufacturer	CIFX RE PLS: 0x00000000- 0xFFFFFFF
		Default: 0
Bus		
Node Id	EPL Node ID (EPL = Ethernet Powerlink)	1239
DNS Node Name	DNS-compatible name of the Powerlink Controlled Node / Slave	
Gateway Address	Gateway address for IP stack	

12.1.4 Powerlink Controlled Node / Slave Parameters

For more see next page

Parameter	Meaning	Range of Value / Value
Data		
Input Data Bytes	Length of the input data in byte	1 1490 Byte,
		Default: 4 Byte
Output Data Bytes	Length of the output data in byte	1 1490 Byte,
		Default: 4 Byte
Disable PdDOMapping	Bit 4 of the stack configuration flags controls whether the mapping version field in the PReq will be checked:	Default: Do not check PReq PDO mapping
Version Check	0 = Check PReq PDO mapping version	version
	1 = Do not check PReq PDO mapping version	
Configure Default Objects	Bit 2 of the stack configuration flags controls whether the default objects have to be configured:	Default: Create default objects
	0 = Do not create default objects	
	1 = Create default objects	
	If the objects will be created, the old set of previously existing objects will be cleared	
Delete Application Objects	Bit 3 of the stack configuration flags controls whether all application objects are to be deleted.	Default: Delete application specific
	0 = Do not delete application objects	objects
	1 = Delete application-specific objects	

Table 69: Powerlink Controlled Node / Slave Parameters



Note: To configure the Managing Node/Master a XDD file (device description file) is required. The settings in the used Managing Node/Master must comply with the settings in the Controlled Node/Slave, to establish a communication. Important parameters are: Vendor ID, Product Code, Serial Number, Revision Number, Node ID, Output and Input length.

12.1.5 **PROFINET IO-Device Parameters**

Parameter	Meaning	Range of Value / Value
Interface		
Bus Startup	Communication start application controlled or automatic	Application controlled, Automatic
Watchdog Time [ms]	Watchdog time within which the device watchdog must be retriggered from the application program while the application program monitoring is activated. When the watchdog time value is equal to 0 respectively the application program monitoring is deactivated.	[0, 20 65535] ms, default = 1000 ms, 0 = Off
I/O Data Status	Status of the input or the output data.	None, (1 Byte, 4 Byte)
	For each input and output date the following status information (in Byte) is memorized in the dual-port memory: Status 0 = None (default) Status 1 = 1 Byte (for future use) Status 2 = 4 Byte (for future use)	
ldent		
Vendor ID	Identification number of the manufacturer, assigned by PROFIBUS Nutzerorganisation e. V.	0 (2 ³² - 1), Hilscher: 011E (hex)
Device ID	Identification number of the device, freely eligibly by the manufacturer, fixed for every device.	0 (2 ¹⁶ - 1), CIFX RE PNS: 103 (hex), Dez 259
		NXSTK 50-RE PNS: 105 (hex), Dez 261
Device Type	Description of the device type, freely eligible	Character string, 0 - 25 characters
Order ID	Hilscher device number (e.g. 1610 100) or order description of the customer for its device	Character string, 0 - 20 characters
Name of Station	Station name of the PROFINET IO-Device station. It has to match the station name configured in the PROFINET IO-Controller for this device. Must be DNS compatible name.	Character string, 1 - 240 characters, Default: See GSDML-File
Type of Station	Type name of the PROFINET station; name can be assigned freely.	Character string, 1 - 240 characters Default: See GSDML-File
Data		
Input Data Length	Length of the input data in Byte	0 1024 Byte Default: 2 Byte
Output Data Length	Length of the output data in Byte	0 1024 Byte Default: 2 Byte

Table 70: PROFINET IO-Device Parameters



Note: To configure the Controller a GSDML file (device description file) is required. The settings in the used Controller must comply with the settings in the Device, to establish a communication. Important parameters are: Station Name, Vendor ID, Device ID, Input and Output data length.



Note: Under **Name of Station** the name must be typed in, which was also used in the configuration file of the master of this device. If no name chosen freely is used in the configuration file, then the name from the GSDML file is used.

12.1.6 SERCOS III Slave Parameters

Parameter	Meaning	Range of Value / Value
Bus Startup	Communication start application controlled or automatic	Application controlled, Automatic
Watchdog Time [ms]	Watchdog time within which the device watchdog must be retriggered from the application program while the application program monitoring is activated. When the watchdog time value is equal to 0 respectively the application program monitoring is deactivated.	[0, 20 65535] ms, default = 1000 ms, 0 = Off
I/O Data Status	Status of the input or the output data.	None, 1 Byte, 4 Byte
	For each input and output date the following status information (in Byte) is memorized in the dual-port memory: Status 0 = None Status 1 = 1 Byte Status 2 = 4 Byte	
Device Address	Address for the SERCOS III Slave.	[1 127]
	The address range is from 1 to 127.	
Object Dictionary	Location of the Object Dictionary for Service Channel: local or Host	local, Host 0= local 1= Host (not supported yet) Default = 0
IP Address	Flag for IP address of the SERCOS III Slave station	Default: none
Netmask	Flag for Network mask of the SERCOS III Slave station	Default: none
Gateway	Flag for Gateway address of the SERCOS III Slave station	Default: none
Flags	BootP: If set, the device obtains its configuration from a BOOTP server. DHCP: If set, the device obtains its configuration from a DHCP server.	Default: none

Table 71: SERCOS III Slave Parameters

13 Lists

13.1 List of Figures

Figure 1: Front Plate Stickers for CIFX 50-RE and CIFX 50E-RE for the labeling of the card LED or of the	
LED of the Ethernet female connector	23
Figure 2: Found new Hardware Wizard - Indicate Software Source	28
Figure 3: Found new Hardware Wizard - Select research- and installation options	29
Figure 4: Found new Hardware Wizard - Software gets installed	30
Figure 5: Found new Hardware Wizard - Software installation has been completed	31
Figure 6: Device Manager > cifXPCI/PCIe Device - correctly installed	32
Figure 7: Dialog Structure of netX Configuration and Diagnostic Utility	35
Figure 8: Select Network Icon Bar	36
Figure 9: Select Language Icon Bar (only English yet)	36
Figure 10: Status Line – Status Fields 1 to 6	38
Figure 11: netX Configuration and Diagnostic Utility	39
Figure 12: Configuration Window	41
Figure 13: Diagnostic Window	43
Figure 14: Diagnostic Window > System	44
Figure 15: Diagnostic Window > Communication	45
Figure 16: Diagnostic Window > Input, Output, Start COM, Stop COM, Reset	46
Figure 17: Device Drawing CIFX 50-RE	48
Figure 18: Device Drawing CIFX 50E-RE	48
Figure 19: Device Drawing CIFX 80-RE	49
Figure 20: Device Drawing CIFX 90-RE	49
Figure 21: Device Drawing CIFX 104C-RE	50
Figure 22: Device Drawing CIFX 104C-RE-R	50
Figure 23: Device Drawing CIFX 104C-RE\F	51
Figure 24: Device Drawing CIFX 104C-RE-R\F	51
Figure 25: Device Drawing Connection Interface AIFX-RE	52
Figure 26: Device Drawing Diagnosis Interface AIFX-DIAG	52
Figure 27: Ethernet pinning at the RJ45 Socket	53
Figure 28: Mini-B USB Connector (5 Pin), S302	55

13.2 List of Tables

Table 1: List of Revisions	7
Table 2: Reference on Hardware	י 8
Table 3: Reference on Software	8
Table 3: Neterence on Sonware Table 4: Directory Structure of the CD	0 0
Table 5: Device Description Files	3 Q
Table 6: Device Description Thes Table 6: Documentations cifX Devices Real Time Ethernet	10
Table 7: Safety Symbols and Sort of Warning or Principle	10
Table 7: Salety Symbols and Solt of Warning of Finiciple	12
Table 0: Signal Words according to ANSI	12
Table 3. Signal Words according to ANSI Table 10: PCI Connector for cifX cords	13
Table 10: PGI Connector for city Slave Device Operation	10
Table 12: Proconditions for citX Master Device Operation	10
Table 12: Installation and Configuration Stone of X Slove Device	10
Table 13: Installation and Configuration Steps city Slave Device	19
Table 14. Installation and Configuration Steps CIX Master Device	20
Table 15. CIX LED Labeling depending of the loaded Firmware	23
Table 16. CIX LED Labeling depending of the loaded Finnware	20
Table 17: Conliguration Steps / USB Device Driver already installed	34
Table 18: Device Identification	30
Table 19: General Buttons	37
Table 20: Status Line Icons	38
Table 21: Select Language Icon Bar (only English yet)	40
Table 22: Select Network Icon Bar: Firmware Buttons Real-Time Ethernet and Fieldbus System	40
Table 23: Descriptions Configuration Windows	42
Table 24: Diagnostic Window > System	44
Table 25: Diagnostic Window > System, Communication	45
Table 26: Start COM, Stop COM, Reset	46
Table 27: Ethernet pinning at the RJ45 Socket	53
Table 28: Ethernet Connection Data	53
Table 29: Use of Hubs and Switches	54
Table 30: Pin out, S302	55
Table 31: Rotary Switch for Slot Number, S1	55
Table 32: Pinning for Cable Connector Ethernet X4 or X304 – Cable 20 pin Ethernet + Status LED	56
Table 33: Pinning for Cable connector DIAG X3 or X303 - Cable 12 pin USB + Status LED	57
Table 34: Pinning for SYNC Connector, X51	57
Table 35: LED Names for each Real Time Ethernet System	58
Table 36: Meaning LED Names	58
Table 37: EtherCAT Master	59
Table 38: Indicator States EtherCAT Master	59
Table 39: EtherCAT Slave	60
Table 40: Indicator States EtherCAT Slave	60
Table 41: EtherNet/IP Scanner (Master)	61
Table 42: EtherNet/IP Adapter (Slave)	62
Table 43: LED Open Modbus/TCP	63
Table 44: LED Powerlink Controlled Node / Slave	64
Table 45: Indicator States Powerlink Controlled Node / Slave	64
Table 46: PROFINET IO-RT Controller	65
Table 47: PROFINET IO-RT-Device	66
Table 48: SERCOS III Slave	67
Table 49: Indicator States SERCOS III Slave	67
Table 50: Technical Data CIFX 50-RE	68
Table 51: Technical Data CIFX 50E-RE	69

Communication Interface Hilscher cifX-RE

Table 52: Technical Data CIFX 80-RE		70
Table 53: Technical Data CIFX 90-RE		71
Table 54: Technical Data CIFX 104C-RE, CIFX 104C-RE-R, CIFX 104C-RE\F,	CIFX 104C-RE-R\F	72
Table 55: Technical Data AIFX-RE		73
Table 56: Technical Data AIFX-DIAG		73
Table 57: EtherCAT Master		74
Table 58: EtherCAT Slave		74
Table 59: EtherNet/IP Scanner (Master)		75
Table 60: EtherNet/IP Adapter (Slave)		76
Table 61: Open Modbus/TCP		77
Table 62: Powerlink Controlled Node / Slave		77
Table 63: PROFINET IO-RT-Controller		78
Table 64: PROFINET IO-RT-Device		79
Table 65: SERCOS III Slave		80
Table 66: EtherCAT Slave Parameters		81
Table 67: EtherNet/IP Adapter Parameters		82
Table 68: Open Modbus/TCP Parameters		85
Table 69: Powerlink Controlled Node / Slave Parameters		87
Table 70: PROFINET IO-Device Parameters		88
Table 71: SERCOS III Slave Parameters		89

14 Glossary

CIFX

	Communication InterFace based on netX
DPM	
	Dual-Port Memory
EDS	
	Electronic Data Sheet
	XML based device description file.
GSDML	
	General Station Description Markup Language
	XML based device description file.
netX Configuration and Diagnostic Utility	

The netX Configuration and Diagnostic Utility allows to operate cifX or netX based devices in different networks. Its graphical user interface serves as configuration tool for the installation, configuration and diagnosis of the devices.

netX

networX on chip, next generation of communication controllers

15 Contacts

Headquarter

Germany

Hilscher Gesellschaft für Systemautomation mbH Rheinstrasse 15 65795 Hattersheim Phone: +49 (0) 6190 9907-0 Fax: +49 (0) 6190 9907-50 E-Mail: info@hilscher.com

Support Phone: +49 (0) 6

Phone: +49 (0) 6190 9907-99 E-Mail: <u>de.support@hilscher.com</u>

Subsidiaries

China

Hilscher Ges.f.Systemaut. mbH Shanghai Representative Office 200010 Shanghai Phone: +86 (0) 21-6355-5161 E-Mail: info@hilscher.cn

Support Phone: +86 (0) 21-6355-5161 E-Mail: cn.support@hilscher.com

France

Hilscher France S.a.r.l. 69500 Bron Phone: +33 (0) 4 72 37 98 40 E-Mail: <u>info@hilscher.fr</u>

Support

Phone: +33 (0) 4 72 37 98 40 E-Mail: <u>fr.support@hilscher.com</u>

Italy

Hilscher Italia srl 20090 Vimodrone (MI) Phone: +39 02 25007068 E-Mail: <u>info@hilscher.it</u>

Support

Phone: +39 / 02 25007068 E-Mail: <u>it.support@hilscher.com</u>

Japan

Hilscher Japan KK Tokyo, 160-0022 Phone: +81 (0) 3-5362-0521 E-Mail: <u>info@hilscher.jp</u>

Support Phone: +81 (0) 3-5362-0521 E-Mail: jp.support@hilscher.com

Switzerland

Hilscher Swiss GmbH 4500 Solothurn Phone: +41 (0) 32 623 6633 E-Mail: info@hilscher.ch

Support

Phone: +49 (0) 6190 9907-99 E-Mail: ch.support@hilscher.com

USA

Hilscher North America, Inc. Lisle, IL 60532 Phone: +1 630-505-5301 E-Mail: <u>info@hilscher.us</u>

Support Phone: +1 630-505-5301

E-Mail: <u>us.support@hilscher.com</u>